


**COLOR INKJET PRINTER**

***JV300-130/160A***

**OPERATION MANUAL**



You can also download the latest manual from our website.

**MIMAKI ENGINEERING CO., LTD.**

URL: <http://mimaki.com/>

D202740-13

Original instructions

# TABLE OF CONTENTS

CAUTION .....	v
DISCLAIMER OF WARRANTY .....	v
Requests .....	v
FCC Statement (USA) .....	v
Interference to televisions and radios .....	v
Foreword .....	v
About usable ink .....	v
On This Operation manual .....	v
Safety Precautions .....	vi
Symbols .....	vi
Safety interlock .....	viii
Warning labels .....	ix
EC DECLARATION OF CONFORMITY .....	xi

## Chapter 1 Before Use

Moving This Machine .....	1-2
Where to Install This Machine .....	1-2
Working Environmental Temperature.....	1-2
Moving This Machine .....	1-2
Names of Parts and Functions .....	1-3
Front Side of the Machine .....	1-3
Rear Side and Right Side of the Machine .....	1-4
Operation Panel .....	1-5
Media sensor.....	1-7
Carriage.....	1-7
Cutter blade and slot for cutting .....	1-7
Capping station .....	1-7
Pinch rollers and Feed rollers.....	1-7
Connecting Cables .....	1-8
Connecting USB2.0 Interface Cable .....	1-8
Connecting the power cable.....	1-8
Inserting ink cartridges .....	1-9
Caution in handling of ink cartridges .....	1-10
Media .....	1-10
Usable sizes of media .....	1-10
Caution in handling of medias.....	1-10
Menu mode .....	1-11

## Chapter 2 Basic Operations

Workflow .....	2-2
Turning the Power ON/OFF .....	2-3
Turning the Power ON.....	2-3
Turning the Power OFF.....	2-3
Setting a Media .....	2-4
Adjusting the Head Height.....	2-4
Setting a roll media.....	2-5
Setting leaf media.....	2-7
Changing the printing origin .....	2-8

Test Printing .....	2-9
Test Printing .....	2-9
Perform test printing with the normal test pattern.....	2-10
Perform test printing with the test pattern for checking white ink ....	2-10
Head Cleaning .....	2-11
About head cleaning.....	2-11
Perform head cleaning depending on the test printing result .....	2-11
Setting of Media Correction .....	2-11
Setting of Media Correction .....	2-11
If the Positions of Dots Shift... ..	2-12
Printing Data .....	2-12
Starting a Printing Operation .....	2-12
Stopping a Printing Operation .....	2-13
Deleting Received Data (Data Clear) .....	2-13
Cutting a media .....	2-13

## Chapter 3 Setup

About SETUP MENU .....	3-2
SETUP MENU table .....	3-3
Register the optimal print conditions to match the use.....	3-4
Setting of Media Correction .....	3-5
If the Positions of Dots Shift... ..	3-6
Setting of Logical Seek.....	3-6
Setting of Drying Time .....	3-7
Setting of Left and Right Margins .....	3-7
Setting of Vacuum Fan .....	3-8
Setting of Feed Speed.....	3-8
Setting of MAPS .....	3-8
Setting Auto Cleaning.....	3-8
Setting Interval wiping .....	3-9
About MACHINE SETUP MENU .....	3-10
MACHINE SETUP MENU table .....	3-11
Setting a AUTO Power-off .....	3-12
Setting the Display of Media Residual.....	3-12
Setting a LANGUAGE .....	3-13
Setting Time .....	3-13
Setting Unit (Temperature/ Length) .....	3-13
Setting a KEY BUZZER.....	3-13
Setting the CONFIRM. FEED .....	3-14
Setting the SPACE FEED MODE .....	3-14
Set the network .....	3-14
Setting event mail function .....	3-15
Initializing the Settings.....	3-19
About INFORMATION MENU .....	3-20
INFORMATION MENU table .....	3-21
Displaying the Information .....	3-21

## Chapter 4 Maintenance

Maintenance .....	4-2
Precautions for Maintenance.....	4-2
About Cleaning Solution .....	4-2
Cleaning the Exterior Surfaces.....	4-2
Cleaning the Platen.....	4-2
Cleaning the Media Sensor.....	4-3
Cleaning the Media Press .....	4-3
About MAINTENANCE MENU .....	4-4
MAINTENANCE MENUs at-a-glance.....	4-5
Maintaining the Capping Station .....	4-6
Cleaning the Wiper and Cap .....	4-6
Washing the Head Nozzle.....	4-7
Washing the Ink Discharge Passage .....	4-8
When the Machine Is Not Used for a Long Time .....	4-8
Cleaning the Ink Head and the Area around It .....	4-10
Automatic Maintenance Function .....	4-11
Setting the Refreshing Intervals .....	4-11
Setting the Cleaning Intervals and Type .....	4-12
Fill up Ink .....	4-12
Replacing consumables .....	4-13
Replacing the wiper.....	4-13
If a Waste Ink Tank Confirmation Message Appears.....	4-13
Replacing the waste ink tank before the waste ink tank confirmation message is displayed .....	4-15
Replacing the Cutter Blade .....	4-15

## Chapter 5 Troubleshooting

Troubleshooting .....	5-2
Power does not turn on .....	5-2
The machine does not start printing.....	5-2
Media get jammed / media is soiled.....	5-2
Image quality is poor .....	5-3
Nozzle is clogged.....	5-3
Ink cartridge warning appears.....	5-4
When the ink leakage occurs .....	5-4
Warning / Error Messages .....	5-5
Warning messages.....	5-5
Error messages.....	5-7

---

## Chapter 6 Appendix

Specifications .....	6-2
Machine specifications .....	6-2
Ink specifications .....	6-3
Setting orders depending on ink type .....	6-4
Setting orders of ink cartridges.....	6-4
Sheet for inquiry .....	6-5

## CAUTION

### DISCLAIMER OF WARRANTY

THIS LIMITED WARRANTY OF MIMAKI SHALL BE THE SOLE AND EXCLUSIVE WARRANTY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS, AND MIMAKI NEITHER ASSUMES NOR AUTHORIZES DEALER TO ASSUME FOR IT ANY OTHER OBLIGATION OR LIABILITY OR MAKE ANY OTHER WARRANTY OR MAKE ANY OTHER WARRANTY IN CONNECTION WITH ANY PRODUCT WITHOUT MIMAKI'S PRIOR WRITTEN CONSENT.

IN NO EVENT SHALL MIMAKI BE LIABLE FOR SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES OR FOR LOSS OF PROFITS OF DEALER OR CUSTOMERS OF ANY PRODUCT.

### Requests

- This Operation manual has been carefully prepared for your easy understanding.  
However, please do not hesitate to contact a distributor in your district or our office if you have any inquiry.
- Description contained in this Operation manual are subject to change without notice for improvement.

### FCC Statement (USA)

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the Operation manual, may cause harmful interference to radio communications.

Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

In the case where MIMAKI-recommended cable is not used for connection of this device, limits provided by FCC rules can be exceeded.

To prevent this, use of MIMAKI-recommended cable is essential for the connection of this printer.

### Interference to televisions and radios

The product described in this manual generates high frequency when operating.

The product can interfere with radios and televisions if set up or commissioned under improper conditions.

The product is not guaranteed against any damage to specific-purpose radio and televisions.

The product's interference with your radio or television will be checked by turning on/off the power switch of the product.

In the event that the product is the cause of interference, try to eliminate it by taking one of the following corrective measures or taking some of them in combination.

- Change the orientation of the antenna of the television set or radio to find a position without reception difficulty.
- Separate the television set or radio from this product.
- Plug the power cord of this product into an outlet which is isolated from power circuits connected to the television set or radio.

## Foreword

Congratulations on your purchase of MIMAKI color ink jet printer "" .

### About usable ink

You can use aqueous sublimation dye ink (Sb53/Sb54) for this machine.

### On This Operation manual

- This Operation manual is describing the operations and maintenance of "Color inkjet printer " (called as this machine hereafter)
- Read this Operation manual carefully and understand them thoroughly to use.
- It is also necessary to keep this Operation manual on hand.
- This Operation manual has been carefully prepared for your easy understanding, however, please do not hesitate to contact a distributor in your district or our office if you have any inquiry.
- Descriptions contained in this Operation manual are subject to change without any notice for improvement.
- In the case when this Operation manual should be illegible due to destruction or lost by fire or breakage, purchase another copy of the Operation manual from our office.
- You can also download the latest manual from our website.

Reproduction of this manual is strictly prohibited.

All Rights Reserved.Copyright

© 2016 MIMAKI ENGINEERING Co., Ltd.












# Safety Precautions

## Symbols

Symbols are used in this Operation Manual for safe operation and for prevention of damage to the machine. The indicated sign is different depending on the content of caution.


Symbols and their meanings are given below. Please follow these instructions as you read this manual.


## Examples of symbols

Meaning	
	Failure to observe the instructions given with this symbol can result in death or serious injuries to personnel. Be sure to read it carefully and use it properly.
	Failure to observe the instructions given with this symbol can result in injuries to personnel or damage to property.
	Important notes in use of this machine are given with this symbol. Understand the notes thoroughly to operate the machine properly.
	Useful information is given with this symbol. Refer to the information to operate the machine properly.
	Indicates the reference page for related contents.
	The symbol "  " indicates that the instructions must be observed as strictly as the CAUTION instructions (including DANGER and WARNING instructions). A sign representing a precaution (the sign shown at left warns of hazardous voltage) is shown in the triangle.
	The symbol "  " indicates that the action shown is prohibited. A sign representing a prohibited action (the sign shown at left prohibits disassembly) is shown in or around the circle.
	The symbol "  " indicates that the action shown must be taken without fail or the instructions must be observed without fail. A sign representing a particular instruction (the sign shown at left instructs to unplug the cable from the wall outlet) is shown in the circle.

## Warning for Use

### WARNING

 • The set of power cables provided with this machine is for use with this machine only, and cannot be used with other electrical devices. Do not use any power cables other than the ones provided with the machine. Failure to observe those instructions may result in fire or electric shocks.

 • Take care not to damage, break or work upon the power cable. If a heavy material is placed on the power cable, or if it is heated or pulled, the power cable can break, thus resulting in fire or electric shocks.

• Do not use this machine in an environment where humidity is high or the machine may get wet. Using the machine under such environment may result in fire or electric shock, or cause malfunction.

• Use of the machine under an abnormal condition where it produces smoke or strange smell can result in fire or electric shocks. If such an abnormality is found, be sure to turn off the power switch immediately and unplug the cable from the wall outlet. Check first that the machine no longer produces smoke, and then contact your distributor or a sales office of MIMAKI for repair.

• Never repair your machine by yourself since it is very dangerous for you to do so.

• Never disassemble or remodel the main unit of the machine or the ink cartridge. Disassembly or remodeling can result in an electric shock or breakdown of the machine.

• Take care that no dust or dirt sticks to Media Transfer Surface. Dust and dirt sticking heaters can cause fire.

• Do not use extension cords. Doing so may result in fire or electric shocks.

• Keep the power plug prong clear of any foreign object such as a piece of metal. Failure to do so may result in a fire or electric shocks.

• Do not plug too many leads into a single socket. Doing so may result in fire or electric shocks.

• Do not use the machine if the power cord or plug is damaged. Using the machine with damaged power cord may result in fire or electric shocks. Contact your service representative for replacement cord.

• Do not handle the power plug with wet hands. Doing so may result in electric shocks.

• Grasp by holding the plug itself when removing the power plug from wall outlet, and never hold by the cord. Holding and pulling the cord may damage the cord, leading to fire or electric shocks.







• If the ink leakage occurs, unplug the power plug to turn off the main power switch, and contact our service office or distributor.





### Hazardous Moving Parts

• Keep Fingers and Other Body Parts Away


• If a foreign object such as a small piece of metal or a liquid such as water gets inside the machine, turn off the machine and unplug the power cord immediately, then consult your service representative. Continuing to use the machine without proper maintenance or repair may result in fire or electric shocks.

**Precautions in Use**

 <b>CAUTION</b>	
<b>Handling of ink</b>	
	<ul style="list-style-type: none"> <li>• If you get ink in your eyes, immediately wash your eyes with a lot of clean water for at least 15 minutes. In doing so, also wash eyes to rinse ink away completely. Then, consult a doctor as soon as possible.</li> <li>• If anyone drinks ink by mistake, keep him or her quiet and see a doctor immediately. Do not allow him or her to swallow the vomit. Then contact the emergency number written in SDS.</li> <li>• If you inhale a lot of vapor and feel bad, immediately move to a location of fresh air and then keep yourself warm and quiet. Then, consult a doctor as soon as possible.</li> <li>• Store ink cartridges in a place that is out of the reach of children.</li> <li>• If the ink adheres to your skin, use a large amount of water and soap or special detergent for skin to remove the ink.</li> </ul>
<b>Handling of the power cable</b>	
	<ul style="list-style-type: none"> <li>• Connect to a socket-outlet with determinate polarity.</li> <li>• For Inlet, be sure to supply power from the outlet of the same voltage.</li> <li>• For PLUGGABLE EQUIPMENT, the socket-outlet shall be installed near the equipment and shall be easily accessible.</li> <li>• Unplug the cord from the wall outlet and remove dust from the power plug periodically, at least once a year. Failure to do so may result in fire or electric shocks.</li> <li>• Do not use the machine unless it is connected to a power supply that satisfies the displayed voltage condition.</li> <li>• Check the voltage of the wall outlet and the capacity of the circuit breaker before you plug the power cords. Plug each power cord to different outlet that has independent circuit breaker. If you plug more than one power cord to wall outlets that share the same circuit breaker, the power may be cut off by the breaker.</li> </ul>
<b>Power supply</b>	
	<ul style="list-style-type: none"> <li>• Leave the breaker turned ON.</li> <li>• Do not turn off the main power switch on the right side of this machine.</li> </ul>
<b>Notes When Handling the Main Unit</b>	
	<ul style="list-style-type: none"> <li>• Use the equipment in a well-ventilated or not-airtight room.</li> <li>• Use the equipment in a well-ventilated or not-airtight room.</li> <li>• Ventilate the room sufficiently before using the equipment.</li> <li>• Do not place the equipment in a humid or dusty place. Otherwise, there is a risk of fire or electrical shock.</li> </ul>
	<ul style="list-style-type: none"> <li>• Do not place the equipment in an unstable place such as on a shaky table and on a tilted surface. The equipment may fall over or drop and cause injury.</li> <li>• The equipment is provided with a built-in media cutter. To replace or feed a printing medium, or to remove a jammed printing medium, do not touch any area other than those specified in this document. Otherwise, there is a risk of injury.</li> <li>• To replace a printing medium, be careful not to pinch your fingers or get injured.</li> <li>• Consult with the service shop about cleaning inside the equipment. Leaving the equipment with dust inside without cleaning for a long time may cause a fire or device failure. Consult with the distributor or service shop for the cost of cleaning inside the equipment.</li> <li>• To move the equipment, contact the nearest service shop.</li> </ul>

 <b>CAUTION</b>	
<b>Note on maintenance</b>	
	<ul style="list-style-type: none"> <li>• When cleaning the ink-station or the heads, make sure to wear the attached goggles and gloves.</li> </ul>
	<ul style="list-style-type: none"> <li>• The gloves supplied with the machine are disposable. When all the gloves are expended, purchase an equivalent product on the market.</li> </ul>
	<ul style="list-style-type: none"> <li>• Do not touch the sharp edge of the blade when replacing the cutter. Touching the sharp edge may result in injury.</li> <li>• Turn off the machine and unplug the power cord from the wall outlet for safety when moving the machine.</li> </ul>

**CAUTIONS and NOTES**

 <b>Warning</b>	
<b>Front cover and lever</b>	
<ul style="list-style-type: none"> <li>• Never open the front cover or raise the lever during printing. Opening the cover or raising the lever will abort printing.</li> </ul>	
<b>Protection of media from dust</b>	
<ul style="list-style-type: none"> <li>• Store media in a bag. Wiping off dust accumulated on media will adversely affect the media due to static electricity.</li> <li>• When leaving the workshop after the working hours, do not leave any media on the roll hanger. If any media is left on the roll hanger, it can get dusty.</li> </ul>	
<b>Periodic replacement parts</b>	
<ul style="list-style-type: none"> <li>• Some parts of this machine must be replaced with a new one periodically by service personnel. Be sure to make a contract with your distributor or dealer for After sale service to ensure a long life of your machine.</li> </ul>	
<b>Disposition of this machine</b>	
<ul style="list-style-type: none"> <li>• Consult your sales or service representative for proper disposal of this machine. Otherwise, commission an industrial waste disposal company.</li> </ul>	
<b>Handling of ink cartridges</b>	
<ul style="list-style-type: none"> <li>• The safety evaluation of this machine assumes that the ink recommended by this company is used. For safe usage of this machine, use the ink recommend by this company</li> <li>• Never refill the ink pack and white ink cartridge with ink. Refilled ink cartridge can cause a trouble. Remember that MIMAKI assumes no responsibility for any damage caused by the use of the ink cartridge replenished with ink.</li> </ul>	
<ul style="list-style-type: none"> <li>• If the ink cartridge is moved from a cold place to a warm place, leave it in the room temperature for three hours or more before using it.</li> <li>• Open the ink cartridge just before installing it in the machine. If it is opened and left for an extended period of time, normal printing performance of the machine may not be ensured.</li> <li>• Make sure to store ink cartridges in a cool and dark place.</li> <li>• Store ink cartridges and waste ink bottle in a place that is out of the reach of children.</li> <li>• Be sure to thoroughly consume the ink in the ink cartridge, once it is opened, within three months. If an extended period of time has passed away after opening the cartridge tank, printing quality would be poor.</li> <li>• Neither pound the cartridge nor shake it violently, as doing so can cause leakage of ink.</li> <li>• Do not touch or stain the contacts of the ink cartridge, as doing so may cause damage to the print circuit board.</li> <li>• Consult your sales or service representative for proper disposal of ink cartridge, ink pack, and waste ink. When you dispose them by yourself, follow the regulations stipulated by the industrial waste disposer or the country or region you live in</li> </ul>	



**Warning**

**Handling of media**







- Use media recommended by MIMAKI to ensure reliable, high-quality printing.
- Pay attention to the expansion and contraction of the media.  
Do not use media immediately after unpacking. The media can be affected by the room temperature and humidity, and thus it may expand and contract. The media have to be left in the atmosphere in which they are to be used for 30 minutes or more after unpacked.
- Do not use curled media.  
The use of curled media can not only cause a media jam but also affect print quality.  
Straighten the sheet of media, if significantly curled, before using it for printing. If a regular-sized coated sheet of media is rolled and stored, the coated side has to face outside.

**Notes on maintenance**

- It is strongly recommended to use the machine in a room that is not dusty.
- Keep the front cover closed even when the machine is not printing. If not, dust can accumulate on the nozzles in the heads.
- Dust in the heads can also cause drops of ink to fall suddenly down on the media during printing. In such a case, be sure to clean up the heads. (P.4-10)
- When cleaning the ink-station or the heads, make sure to wear the attached gloves. Further, when the solvent ink is used, it is necessary to wear the attached goggles.
- Perform wiping (removal of dust and paper powder) of the capping station and wiper frequently.
- The safety evaluation of this machine assumes that the ink recommended by this company is used. For safe usage of this machine, use the ink recommend by this company
- Never refill the ink pack and ink cartridge with ink. Refilled ink cartridge can cause a trouble. Remember that MIMAKI assumes no responsibility for any damage caused by the use of the ink cartridge replenished with ink.
- If the ink cartridge is moved from a cold place to a warm place, leave it in the room temperature for three hours or more before using it.
- Open the ink cartridge just before installing it in the machine. If it is opened and left for an extended period of time, normal printing performance of the machine may not be ensured.
- Make sure to store ink cartridges in a cool and dark place.
- Store ink cartridges and waste ink bottle in a place that is out of the reach of children.
- Be sure to thoroughly consume the ink in the ink cartridge, once it is opened, within three months. If an extended period of time has passed away after opening the cartridge tank, printing quality would be poor.
- Neither pound the cartridge nor shake it violently, as doing so can cause leakage of ink.
- Do not touch or stain the contacts of the ink cartridge, as doing so may cause damage to the print circuit board.
- Consult your sales or service representative for proper disposal of ink cartridge, ink pack, and waste ink.  
When you dispose them by yourself, follow the regulations stipulated by the industrial waste disposer or the country or region you live in.


**Cautions on Installation**

**CAUTION**

<b>A place exposed to direct sunlight</b>	<b>On an inclined surface</b>
	
<b>A place that vibrates</b>	<b>A place exposed to direct air flow from an air conditioner or the like.</b>
	
<b>A place where temperature or humidity varies significantly</b>	<b>Around a place where fire is used</b>
<p></p> <ul style="list-style-type: none"> <li>• Use the machine under the following environmental conditions:</li> <li>• Operating environment: 20 to 30 °C (68 to 86 °F) 35 to 65 % (Rh)</li> </ul>	


**Safety interlock**







This machine is equipped with interlocks to terminate the operation for your safety when the cover opens during printing etc. (red circle parts in the figure below).



# Warning labels

Warning labels are stuck on the machine. Be sure to fully understand the warning given on the labels. If a warning label is illegible due to stains or has come off, purchase a new one from a distributor or our sales office.



No.	Reorder	Label
1	M910931	
2	M907833	
3	M903330	
4	M903405	
5	M907935	
6	M905811	

## EC DECLARATION OF CONFORMITY

We hereby declare that the following our product conforms with the essential health and safety requirements of EC Directives.

Product            Inkjet Printer  
Model No.        JV300-160A  
                      JV300-130A

Manufacturer     MIMAKI ENGINEERING CO.,LTD.  
                      2182-3, Shigeno-otsu, Tomi, Nagano,  
                      389-0512, JAPAN

Authorised Compiler in the Community  
                      MIMAKI EUROPE B.V.  
                      Stammerdijk 7E 1112 AA Diemen,  
                      The Netherlands

Directives        Machinery Directive2006/42/EC  
                      Low Voltage Directive2014/35/EU  
                      EMC Directive2014/30/EU  
                      RoHS Directive2011/65/EU

The above product has been evaluated for conformity with above directives using the following European standards. The technical construction file (TCF) for this product is retained at the above Manufacturer's location.

Machinery Directive / Low Voltage Directive  
                      ENISO12100:2010, EN60204-1:  
                      2006+A1,EN60950-1:  
                      2006+A11+A1+A12

EMC Directive    EN55022:2010, EN61000-3-2:  
                      2006+A1+A2, EN61000-3-3:2008, EN55024:2010

RoHS Directive    EN50581:2012

# Chapter 1

## Before Use



### This chapter

describes the items required to understand before use, such as the name of each part of the machine or the installation procedures.

Moving This Machine .....	1-2	Connecting Cables.....	1-8
Where to Install This Machine .....	1-2	Connecting USB2.0 Interface Cable .....	1-8
Working Environmental Temperature .....	1-2	Connecting the power cable .....	1-8
Moving This Machine .....	1-2	Inserting ink cartridges .....	1-9
Names of Parts and Functions.....	1-3	Caution in handling of ink cartridges .....	1-10
Front Side of the Machine .....	1-3	Media .....	1-10
Rear Side and Right Side of the Machine ...	1-4	Usable sizes of media .....	1-10
Operation Panel .....	1-5	Caution in handling of medias .....	1-10
Media sensor .....	1-7	Menu mode .....	1-11
Carriage .....	1-7		
Cutter blade and slot for cutting .....	1-7		
Capping station .....	1-7		
Pinch rollers and Feed rollers .....	1-7		


# Moving This Machine

## Where to Install This Machine

Secure a suitable installation space before assembling this machine.

The place of installation must have enough space for not only this machine itself, but also for the printing operation.

Model	Width	Depth	Height	Gross weight
JV300-130A	2525mm (99.4in )	700mm (27.6in)	1392mm (54.8in)	170kg (374.8lb)
JV300-160A	2775mm (109.3in)	700mm (27.6in)	1392mm (54.8in)	200kg (440.9lb)



## Working Environmental Temperature

Use this machine in an environment of 20 to 30°C to ensure reliable printing.

## Moving This Machine

Move this machine according to the following steps when this machine needs to be moved on the same step-free floor.




- When the machine is moved to any place other than on the same step-free floor, contact your distributor or our service office. If you move it by yourself, failure or damage may occur. Be sure to request your distributor or our service office to move this machine.



- When moving this machine, take care that it does not receive a significant impact.
- Be sure to lock the casters after moving of this machine.

**1**


**Release the lock of caster.**



**2**


**Move this machine as shown in the figure.**

- For safety, be sure to operate it with 4 people or more.
- Do not push the cover to move this machine since the cover may be broken.



**3**

**Lock the caster.**



# Names of Parts and Functions

## Front Side of the Machine

### Maintenance cover (upper)

Open the cover in maintenance.  
Even when the power switch is off, keep all covers closed.

### Ink cartridges

Each cartridge contains an ink of a particular color.

### Cartridge protection cover

This prevents an injury or breakage of the machine due to a protrusion of the ink cartridge. (It is located under the ink cartridge.)

### Front cover

Open the cover in setting of medias, taking of measures against jamming of medias or in maintenance inside the station.  
Even when the power switch is off, keep this cover and the other covers closed.

### Clamp lever (front)

Moves the pinch rollers up and down to hold or release the media.

### Carriage

Move the print head unit from side to side.

### Operation panel

This panel has the operation keys required for operating the machine and the LCDs for displaying setting items, etc.

### Waste ink tank

Waste ink gathers in this tank.

### Stand

Supports the main body of the machine. It is provided with casters that are used to move this machine.




### Platen

The printed media is sent out, sliding on the platen.

### Maintenance cover (lower)

Open the cover in maintenance.  
Even when the power switch is off, keep all covers closed.

# Rear Side and Right Side of the Machine





## Operation Panel


Use the operation panel to make settings for printing or operate this machine.

**SEL key**

Changes over the functions of the function keys ([FUNC1]–[FUNC3]).

**[FUNC1] / [FUNC2] / [FUNC3] key**

Press this to set various functions or to do test printing. The function keys' functions are changed each time [SEL] key is pressed.



**Display**

Displays the following items:

- Printer status
- Set media width
- Ink status<sup>\*1</sup>
- Functions assigned to [FUNC1] to [FUNC3]<sup>\*2</sup>

**JOG key**

Use these keys to shift the carriage or the media in [LOCAL]. Also use them to select an item of printing conditions.

**[END/POWER] key**

Cancels the last input value or returns the setting menu to the immediate higher level of the hierarchy. Also, press this to turn the power on or off. (Give it a long press to turn the power off.)

**[ENTER] key**

Registers the last input value as the setting value or goes to the immediate lower level of the hierarchy.

**Status indicator lamp**

Indicates the machine's status (printing, error occurred, etc).

Condition of Lamp	Condition of machine
OFF	Machine is in LOCAL mode, no print data has been received, and no errors have occurred.
Lit steady Light blue	Switched to REMOTE mode.
Flashing Light blue	Currently printing.
	In test printing: printing a pattern stored inside the machine.
Lit steady blue	Print data still remains in the machine.
Flashing red	Error has occurred.
Lit steady red	Error (SYSTEM HALT) has occurred.



- The power switch under the operation panel lights in blue when the power is turned on, and off when the power switch is turned off. The ink clogging prevention function is periodically operated even when the power switch is OFF if the main power switch keeps being ON. (Auto maintenance function) P.1-4














### \*1 : Ink Status

Status of the ink cartridge (remaining ink/error, etc.) is displayed using icons. Each icon is described below.

Icon	Contents																		
	<p>The remaining amount of ink is displayed in 9 stages. The remaining amount decreases moving to the right.</p> <table border="1" style="width: 100%; text-align: center; border-collapse: collapse;"> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>ink full</td> <td>Approximately 1/8 consumed</td> <td>Approximately 1/4 consumed.</td> <td>Approximately 3/8 consumed.</td> <td>Approximately 1/2 consumed.</td> <td>Approximately 5/8 consumed.</td> <td>Approximately 3/4 consumed.</td> <td>Approximately 7/8 consumed.</td> <td>near end</td> </tr> </table>										ink full	Approximately 1/8 consumed	Approximately 1/4 consumed.	Approximately 3/8 consumed.	Approximately 1/2 consumed.	Approximately 5/8 consumed.	Approximately 3/4 consumed.	Approximately 7/8 consumed.	near end
ink full	Approximately 1/8 consumed	Approximately 1/4 consumed.	Approximately 3/8 consumed.	Approximately 1/2 consumed.	Approximately 5/8 consumed.	Approximately 3/4 consumed.	Approximately 7/8 consumed.	near end											
	Displayed at ink end (only when the 4-color ink set is used) and ink near end.																		
	Indicates that the cartridge cannot be used due to ink end or ink error (remaining ink 0, cartridge not attached, etc.).																		
	Indicates that ink has expired or that one month has passed after the expiration date. Please use quickly. Ink can no longer be used if two months have passed after the expiration date.																		

## \*2 : Functions assigned to [FUNC1] to [FUNC3]

Contents of functions assigned to [FUNC1] to [FUNC3] are described below.

Icon	Contents
	Displays "MENU" for setting functions.
	Displays maintenance functions such as test print, cleaning, etc.
	Shifts to REMOTE from LOCAL and starts printing.
	Displays adjustment functions such as FEED COMP, DROP.POScorrect, etc.
	Executes data clear.
	Suspends printing in REMOTE and shifts to LOCAL.
	Executes media cut.
	When there are multiple items on the MENU screen or other screens, it moves to the previous page.
	When there are multiple items on the MENU screen or other screens, it moves to the next page.
	Used for completing confirmation when warning message has been displayed and so on.
	Used for turning functions OFF or cancelling them.
	Some kind of setting or function is assigned. Operate according to the description of each function.
	Switches between enable/disable when selecting multiple items, for example, when selecting target head for cleaning and so on.




- The color of icons changes according to the state of the printer.
  - When the icon is green : The printer is in REMOTE mode.
  - When the icon is dark blue : The printer is in LOCAL mode.
  - When the icon is yellow : A warning has been issued.
  - When the icon is red : An error has been issued.

## Media sensor

The media sensor detects the presence of the media and the media length.

This machine has one media sensor on the platen (in the rear).




**Important!**

- When setting a media, be sure to cover the media sensors located on the rear of the platen. The media cannot be detected unless it is placed over the sensor.

## Carriage

The carriage is provided with the ink heads for printing, the cutter unit for cutting off the sheet of media, etc.


A lever is also provided to adjust the height of Head in 3 stages according to the thickness of media. (☞ P.2-4)



## Cutter blade and slot for cutting

The carriage is provided with a cutter unit for cutting off the media that has been printed on.

The cutter cuts off the sheet of media along the slot for cutting on the platen.



## Capping station

The capping station consists of the ink caps, the wiper for cleaning the heads, etc.


The ink caps prevent the nozzles in the ink heads from drying up.

The wiper cleans the nozzles in the heads.

The wiper is consumable. If the wiper is deformed or the media is stained, replace the wiper with a new one.



- Be sure to wear the attached goggles in cleaning within the capping station to protect your eyes against ink. Otherwise, you may get ink in your eyes.




## Pinch rollers and Feed rollers

This machine retains the media with the pinch rollers and feed rollers. During printing operation, the feed rollers feed the media forward.


**Important!**

- Keep the pinch rollers lifted up when this machine is not in use. If the pinch rollers are left lowered for an extended period of time, they can be deformed and fail to securely retain the media.



# Connecting Cables

## Connecting USB2.0 Interface Cable



Connect the PC and this machine with the USB2.0 interface cable.



- Your RIP must be compatible with USB 2.0.
- Contact a RIP maker near your location or our office when the USB2.0 interface is not attached to the PC.


## Notes on USB 2.0 Interface



- Your RIP must be compatible with USB 2.0.

### When two or more JV300 machines are connected to one personal computer

When two or more JV300 machines are connected to one personal computer, the personal computer may not recognize all the JV300 machines normally. Reconnect the unrecognized JV300 machine to another USB port, if available, and check to see if it is recognized. If the JV300 machine is not recognized by the newly connected USB port, use USB 2.0 repeater cables available on the market.



### Notes on peripheral devices in USB high speed mode

When a peripheral device (USB memory or USB HDD) to be operated in USB high speed mode is connected to the same personal computer that a JV300A machine is connected to, the USB device may not be recognized.


When JV300A is connected to the personal computer to which an external HDD is connected via USB, the speed of data output to JV300A may drop. That can cause the head unit to stop temporarily at the right or left end during printing.

### Removing USB memory

If a USB memory module is inserted in the personal computer to which a JV300A machine is connected, click "Stop" in the "Safely Remove Hardware" window by following the instructions given there first and then remove the module.


Leaving a USB memory module inserted can cause [ERROR 10 COMMAND ERROR].

Copy the data onto the hard disk before outputting it for printing.



## Connecting the power cable


### 1 Insert the power cable into an inlet of the machine.



### 2 Secure a cable band.

- Secure the cable with the cable band attached to this machine.

### 3 Insert the power plug into a plug socket.



- Do not use any power cables other than the attached power cable.




- Be sure to connect the power cable to the outlet near this machine, and make sure that the power cable can be easily removed.
- Connect the power cable to the grounded outlet. Otherwise, it may result in fire or an electric shock.


# Inserting ink cartridges

Insert an ink cartridges.

- 1 Shake the ink cartridge as shown on the right.**



- 2 Insert the ink cartridge.**



- Insert the ink cartridge lengthwise with the surface having IC chips pointing to the left side.
- Colors are displayed on the display as follows.  
Black: K, Blue: B, Magenta: M, Yellow: Y,  
Light blue: b, Light magenta: m

## Changing an ink cartridge

Perform as follows when [INK END] or [INK NEAR END] is displayed on the display.

### ● When [INK END] is displayed

- (1) Pull out an ink cartridge to be replaced.
- (2) Insert a new ink cartridge, paying attention to the direction of IC chip.

### ● When [INK NEAR END] is displayed

There is a little of ink left. It is recommended to replace the ink cartridge soon since ink may become empty in printing while printing is continuously enabled.




- During [INK NEAR END] is displayed, Auto cleaning does not operate. (P.3-8)

## For Ink cartridge lamps

The condition of the ink cartridges set in the machine is confirmable with lamps located over the ink cartridges.

Ink cartridge lamps



Condition of Lamp	Description
Lit to green	No error (ink is being supplied)
OFF	No error
Lit or blinks to yellow	One of the following errors occurs. <ul style="list-style-type: none"> <li>• Ink near-end</li> <li>• Ink end</li> <li>• Expiration of a term of ink validity (one month)</li> </ul>
Blinks to red	Expiration of a term of ink validity (two months)
Lit to red	One of the following errors occurs. <ul style="list-style-type: none"> <li>• No ink left</li> <li>• No ink cartridge inserted</li> <li>• Other ink errors (P.5-6)</li> </ul>

## About ink expiration date

The ink cartridge has its expiration date.

When this expiration date is exceeded, a message is displayed in LOCAL and for the guidance message. (P.5-5, P.5-6)

You can use the cartridge in two months after the expiration date indicated on it, however, you cannot use it when three months have passed from the expiration date. As LED will blink quickly to inform you of it, replace the cartridge

Ex.) When the expiration date is April 2016

May : Usable

June : Usable (LED lits to yellow)

July : Unusable (LED blinks to red)

## Caution in handling of ink cartridges



- Use genuine ink cartridges for this machine. This machine functions by recognizing the genuine ink cartridges. In case of troubles caused by modified ink cartridges or the like, it shall be out of the warranty even within the warranty period.
- If the ink cartridge is moved from a cold place to a warm place, leave it in the room temperature for three hours or more before using it.
- Be sure to thoroughly consume the ink in the ink cartridge, once it is opened, within three months. If an extended period of time has passed away after opening the cartridge tank, printing quality would be poor.
- Make sure to store ink cartridges in a cool and dark place.
- Store ink cartridges and waste ink tank in a place that is out of the reach of children.
- Request an industrial waste processor for processing of empty ink cartridges.
- Do not shake ink cartridges violently. This may result in ink leakage from the ink cartridges.
- Never refill the ink cartridges with ink. This may result in troubles.  
MIMAKI will not bear any responsibility for any damage caused by the use of the ink cartridges refilled with ink.
- Do not touch or stain the contacts of the ink cartridge. This may cause damages on printed circuit boards.
- Do not disassemble the ink cartridges.



## Media

Usable media sizes and notes for handling are described.

### Usable sizes of media

Model	JV300-130A	JV300-160A
Type of Recommended media	Photo-paper/ Synthetic paper/ Duplex paper	
Maximum width	1371mm	1620mm
Minimum width	210mm	210mm
Maximum printing width	1361mm	1610mm *1
Roll media	Thickness	1.0mm or less
	Roll outside diameter	Φ250mm or less (paper media) Φ210mm or less (others)
	Roll weight	40kg or less
	Roll inside diameter	3 or 2 inches
	Side printed	Side facing outward

\*1. When "MARGIN(RIGHT/LEFT)" in the Setup menu has been set to the minimum (-10 mm).

### Caution in handling of medias

Pay attention to the followings for handling of medias.



- **Use media recommended by MIMAKI to ensure reliable, high-quality printing.**  
Set the heater temperature to meet the characteristics of the media.
- **Pay attention to the expansion and contraction of the media.**  
Do not use media immediately after unpacking. The media can be affected by the room temperature and humidity, and thus it may expand and contract.  
The media have to be left in the atmosphere in which they are to be used for 30 minutes or more after unpacked.
- **Do not use curled media.**  
This may result in paper jamming.  
If a regular-sized coated sheet of media is rolled and stored, the coated side has to face outside.
- **Be careful to dusts on the edge face of the media.**  
Some rolls have dusts contained in the package gathered on the edge surface of the roll. If you use as it is, the drawing quality may be degraded due to nozzle missing or ink drops. Be sure to set the roll after removing dusts adhering on the edge face of the roll.

# Menu mode

This machine has 4 modes. Each menu mode is described below.

## NOT-READY mode

This is the mode in which the media has not been detected yet.


## LOCAL mode

Local mode is the mode for the drawing preparation state.

All the keys are effective.

The machine can receive data from the computer. However, it does not perform printing.

### Screen display in Local mode



This mode permits the following operations:

- Pressing the JOG keys to set up a drawing origin and drawing area.
- Pressing the [ENTER] key to check the remaining amount of ink, the description of the cartridge error, the model name, the firmware version, and so on.

## MENU mode

To set MENU mode, press the [FUNC1] key when this machine is in LOCAL mode.

In this mode, each function can be set.

## REMOTE mode

This machine prints the data it receives.





# Chapter 2

## Basic Operations



### This chapter

describes procedures and setting methods for ink and media preparation, and printing.

Workflow .....	2-2	Setting of Media Correction .....	2-11
Turning the Power ON/OFF .....	2-3	Setting of Media Correction .....	2-11
Turning the Power ON .....	2-3	If the Positions of Dots Shift... ..	2-12
Turning the Power OFF .....	2-3	Printing Data .....	2-12
Setting a Media .....	2-4	Starting a Printing Operation .....	2-12
Adjusting the Head Height .....	2-4	Stopping a Printing Operation .....	2-13
Setting a roll media .....	2-5	Deleting Received Data (Data Clear) .....	2-13
Setting leaf media .....	2-7	Cutting a media .....	2-13
Changing the printing origin .....	2-8		
Test Printing .....	2-9		
Test Printing .....	2-9		
Perform test printing with the normal test pattern .....	2-10		
Perform test printing with the test pattern for checking white ink .....	2-10		
Head Cleaning .....	2-11		
About head cleaning .....	2-11		
Perform head cleaning depending on the test printing result .....	2-11		

## Workflow

**1** Turning the Power ON/OFF

Referring to “Turning the Power ON/OFF” (☞ P.2-3).

**2** Setting a Media

Referring to “Setting a Media” (☞ P.2-4).

**3** Test Printing

Referring to “Test Printing” (☞ P.2-9).

**4** Head Cleaning

Referring to “Head Cleaning” (☞ P.2-11).

**5** Printing Data

Referring to “Printing Data” (☞ P.2-12).

## Turning the Power ON/OFF

### Turning the Power ON

This machine is provided with the following two power switches:

#### Main power switch :

It is located on the side of this machine. Keep this switch ON all the time.


#### [END/POWER] key :

Normally, use this key to turn the power ON/OFF.

The nozzle clogging prevention function periodically operates even with the [END/POWER] key turned OFF when the main power switch is turned ON.

#### 1 Turn the main power switch ON.

- Set the main power switch located on the side of this machine to the "I" side.



- The firmware version is displayed when the power is turned ON, and then the machine performs its initial operation.

#### 2 Turn the power on, by pressing the [END/POWER] key.

- The machine enters LOCAL.

#### 3 Turn ON the power of the connected PC.

**Important!**

- Turn the power ON after the front cover and maintenance cover are closed.
- The head nozzle may result in nozzle clogging if the main power switch is left OFF for a long time.

### Turning the Power OFF

When having ended the operation of the machine, turn the power OFF by pressing the power switch located on the front side.


Check the following items when turning the power OFF.

- If the machine is receiving data from the PC or if there is any data that has not been output yet
- If the head has returned to the capping station
- If any error has occurred  
(☞ P.5-7 "Error messages")

#### 1 Turn OFF the power of the connected PC.

#### 2 Turn the power off, by giving the [END/POWER] key a long press.

- Do not turn OFF the main power switch located on the side of the machine.
- To use this machine again, press the [END/POWER] key .



### Cautions about Turning the Power OFF

#### ● Do not turn the main power switch OFF.

When the main power switch is ON, the power periodically turns ON and the nozzle clogging prevention function (flushing function) operates. When the main power switch has been turned OFF, the auto maintenance functions, such as flushing, do not operate, and this may cause nozzle clogging.

#### ● Keep the front cover and the maintenance cover closed.

If the cover is opened, the auto maintenance function such as the flushing function does not work.

#### ● Turn the power OFF after having checked the position of the head.

If the power is turned OFF in a state where the head has not returned to the capping station, the ink head dries, which may cause nozzle clogging.

In this case, turn the power ON again and check that the head has returned to the capping station, and then turn the power OFF.

#### ● Do not turn the power OFF during printing.

The head may not return to the capping station.

#### ● After having turned the power switch OFF by pressing [END/POWER] key, turn the main power switch OFF.

When turning the main power switch off for moving the machine or for solving the error or the like, press the [END/POWER] key a long time on the front of the machine, check the display is turned off on the operation panel, and then turn the main power switch off.

# Setting a Media

This machine can be used with a roll media and leaf media.

For usable medias, refer to P.1-10 "Usable sizes of media".




- Take care not to drop the media on your foot when setting the media. It may cause an injury due to the media.
- When setting a roll media, work by two or more people. Otherwise, you may hurt your back by the weight of the roll media.
- Adjust the head height prior to setting the media. If the head height is adjusted after the media is set, this may cause a media jamming, deterioration of the print quality or head damage.
- The range of the initial head height is adjustable by 2 levels according to the purpose of use.
- The range of the printing height of this machine is from L range (2 mm/3 mm) to H range (3 mm/4 mm). (Set to L range 2 mm at shipping)


## Adjusting the Head Height

Adjust the head height according to the thickness of the media you use.

- 1 Move the carriage to the platen.**
  - When the device is turned ON :Execute [ST.MAINTENANCE - CARRIAGE OUT] of the Maintenance functions. (P.4-6 Step1,2)
  - When the device is turned off : Open the front cover, then move the carriage by hand.




- 2 Loosen the screw in front.**
  - Loosen the screws, rotating each by one turn of a standard screwdriver.




- 3 Adjust the height-adjusting lever according to the media.**
  - Adjust the position of the lever, referring to P.2-4 "For the Adjusting Lever and the Range".
  - Set the height-adjusting lever to the highest stage or the lowest stage. Setting it to the intermediate height, a printing fault can result.


Height-adjusting lever



- 4 Fix the carriage.**
    - Fasten the screw securely.
- Important!**
- Please do not press, and do not push up Height-adjusting lever up below when you tighten the screw when Height-adjusting lever is set to L range or H range.



- 5 Return the carriage to the station position.**



## For the Adjusting Lever and the Range

Range	Head height	Note
L range	2mm (The set position at shipping)	You can raise the base of the head height 1 to 2 mm higher. To do this, contact one of our sales representatives.
M range	2.5mm	
H range	3mm	



- Set the lever to "H range" when the media is prone to gather dust in the head or is often stained with ink traces.




- When the ink is changed from dye ink to other aqueous ink, or on the contrary, after the machine is installed, the adjustment is required for the head initial height (H/L range). Consult with our sales office about it.

## Setting a roll media


Set a roll media to the roll media hanger located on the back of this machine.

**1** Move the roll holder located in the back of the device to the direction of the middle of the device.

- Loosen the roll holder fixing screw and then move it.



**2** Check the clamp lever is lowered.




**3** Move the roll holder to the roll setting position.

- Check the roll stopper is not caught between the roll stopper arm and this machine.

Set the base position of roll holder within this range.

Roll Holder Set Position	3 Inch Roll Media	◀	▶
	2 Inch Roll Media	◀	▶

- There are two types of the internal diameter of the roll media paper tube: 2 inch and 3 inch.




Roll Holder Side (The back of this machine)

**4** Tighten the roll holder fixing screw.


- Check the Step 2 to 3 again.

**5** Set the left end of the core of the roll media on the left roll holder.


- Push the roll media onto the roll holder until the roll core is all the way seated.




**6** Loosen the screw of the right side roll holder then insert the holder into the core of the roll media.



**7** Raise the clamp lever in the rear of this machine.



**8** Insert the roll media in this machine.




- The roll media can be smoothly inserted by slanting the media.

- (1) Pull the media out of the roll to the head of the platen.
- (2) Insert the media between the platen and the pinch roller.
  - Pull the media out of the roll so that the media can be grasped from the front of the machine.
- (3) Push down the clamp lever from the back of this machine.
  - The media is held.


**9** Pull out the roll media out.

- (1) Open the front cover.
- (2) Raise the clamp lever from the front of this machine.
- (3) Pull out the roll media gently and then stop pulling when locked lightly.




**10** Make the roll media even then lower the clamp lever.

- Pulling several positions of the media lightly, Lower the clamp lever after confirming that the amount of the roll media pulled out is almost even.





**11** Hold the media with the media press gently.

- Set the media so that no media sticks out from the right end pinch roller to the right side.
- When using a thick media, remove the media press from the media before printing.



- When installing the media, align the media's right edge with the groove in the platen. Placing the media rightward of the groove will make it rise up if it moves obliquely, and this could cause damage to the head.
- If a media is misaligned to the right/left more than fixed position, a error message "MEDIA SET POSITION R" is displayed. Set the media again.



**12** Close the front cover.**13** Press the  key to select "ROLL".





- Detects the media width.
- When [MEDIA RESIDUAL] of the maintenance function is "ON" (☞ P.3-12), the screen for entering media remaining amount is displayed after detecting the media width. (☞ P.2-7)

**Entering the media remaining amount**


When [MEDIA RESIDUAL] of the maintenance function is "ON" (☞ P.3-12), the screen for entering media remaining amount is displayed after detecting the media width.

**1** Display the screen for entering media remaining amount.**2** Press   to enter the media remaining amount.**3** Press the  key.**About the media residual print**


When [MEDIA RESIDUAL] of the maintenance function is "ON" (☞ P.3-12), You can print a list of print the current date and media remaining.

**1** In Local, Press    .

- It enters into the origin setting mode.

**2** Press the  key.


- Appear the confirmation screen of media remaining print.

**3** Press the  key.


- Media residual print starts.

**Setting leaf media**


Unlike roll media, leaf media does not need to be retained with the roll holders.

**1** Open the front cover, and raise the clamp lever.**2** Insert the leaf media between the platen and the pinch rollers.

- Set the media so that no media sticks out from the right end pinch roller to the right side.


**3** Hold the media with the media press gently.

- Set the media so that no media sticks out from the right end pinch roller to the right side.
- When using a thick media, remove the media press from the media before printing.




**4** Push down the clamp lever and close the front cover.

- Set the media straight.



**Important!**

- Set the media on the black part of the platen so that it comes out approximately 40mm. If it is shorter than that, it may not be able to perform the media detection.



**5** Press the **ENTER** key.

**6** Press the **▶** key to select "LEAF" .


**7** The media detection is started.

- (1) The media width is detected.
- (2) The media is fed then the rear end of media is detected.
- (3) It returns to the Local when the detection is completed.

**Notes when using media press**



- When installing the media, align the media's right edge with the groove in the platen. Placing the media rightward of the groove will make it rise up if it moves obliquely, and this could cause damage to the head.
- If a media is misaligned to the right/left more than fixed position, a error message "MEDIA SET POSITION R" or is displayed. Set the media again.




**Changing the printing origin**

The position of the printing origin can be changed. Moving the LED pointer to the changing position and deciding the position.

**1** In Local, Press **▲▼◀▶** .

- It enters into the origin setting mode.



**2** Set a light point of the LED pointer to the changing position by pressing **▲▼◀▶** .


- Select the carriage and media, moving the point with **[▲][▼][◀][▶]**.

**3** After determining the origin, press the **ENTER** key.

- The printing origin is changed.

**Typical setting position of printing origin**

The printing origin in the depth direction (X') is positioned at about 75 mm rearward from the slot for cutting on the platen. The printing origin in the scanning direction (Y') is positioned at 15 mm from the right end of the media. The value in the scanning direction (Y') can be changed using [MARGIN] in FUNCTION mode. (P.3-7) This can be changed by using the Jog key.






# Test Printing

Print a test pattern to check that there are no discharging defects such as nozzle clogging (slight touching of ink or nozzle missing).

## Relationship between head row and test pattern

The relations between head row and test pattern print position are as follow.




## About test patterns


This machine provides you two test patterns.

### ● Normal test pattern (when using ink other than white ink)

When you use ink that you can check by printing a test pattern on a white media, print this test pattern.



### ● Test pattern for checking white ink



## Note on test printing




- When using leaf media, set a media of more than A3 size put horizontally. If a media with narrow width is set, printing will only be conducted to midway.
- When using a roll media, rewind the media by hand before printing so that it is not loose. When the roll media has not been rewound tightly, it may cause image quality to deteriorate.

## Test Printing

Print a test pattern to check that there are no discharging defects such as nozzle clogging (slight touching of ink or nozzle missing).

In addition, you can select the orientation of the test pattern to print from two types in order to perform test printing repeatedly. Select one depending on your use.



- : When the set value is "FEED DIR."
- : When the set value is "SCAN DIR."


### Check before test printing.

- If a media has been set P.2-4
- If the origin position has been set
- If the head gap has been adjusted P.2-4


## Perform test printing with the normal test pattern

- 1** Press the **FUNC2** (TEST PRINT/CLEANING), and press the **ENTER** key in LOCAL.
  - TEST PRINT MENU will be displayed.
  - Press [**▲**][**▼**] to change the test pattern orientation. The orientation selected here will be reflected on when you will print next time.
  - When performing test printing after having changed the orientation from "SCAN DIR." to "FEED DIR.", the line is fed to the position of the first test printing.
- 2** Press the **ENTER** key.
  - Test printing starts.
  - When the printing has been completed, the screen returns to LOCAL.
- 3** Check the printed test pattern.
  - When the result is normal, end the operation.
  - When the result is abnormal, perform head cleaning. (☞ P.2-11)

Normal pattern



Abnormal pattern




## Perform test printing with the test pattern for checking white ink


It makes easier to check if print the background to the white ink locations in the pattern.

- 1** Press the **FUNC2** (TEST PRINT/CLEANING), and press the **ENTER** key in LOCAL.
  - TEST PRINT MENU will be displayed.
- 2** Press **▲** **▼** to select "SpotColor Check".
- 3** Press the **ENTER** key.
  - Print a test pattern in the following orders.
    - (1) Print the pattern daubed with black.
    - (2) Dry the pattern for thirty seconds.
      - When press the [ENTER] key, cancel waiting time and shift to step (3).
    - (3) Return the media automatically and print the test pattern.
- 4** Check the printed test pattern.
  - When the result is normal, end the operation.
  - When the result is abnormal, perform head cleaning. (☞ P.2-11)

Normal pattern



Abnormal pattern



# Head Cleaning

## About head cleaning

Check the printed test pattern result and perform cleaning depending on the status.

Select one from the four types below:

**NORMAL** : When any line is missing

**SOFT** : When only head wiping is needed (when lines are bent)

**HARD** : When poor image quality cannot be improved even by NORMAL or SOFT cleaning

**ULTRA** : When poor image quality cannot be improved even by HARD cleaning

## Perform head cleaning depending on the test printing result

There are four types of head cleaning. Use one by checking the test pattern.

**1** Press the **FUNC2** (TEST PRINT/CLEANING) key in LOCAL.

- CLEANING MENU will be displayed.

**2** Press **▲ ▼** to select the cleaning type.

- **NORMAL** : Select this if any line is missing.
- **SOFT** : When only head wiping is desirable. (in case of bent lines)
- **HARD** : Select this if inferior printing cannot be improved even by [NORMAL] or [SOFT] cleaning.
- **ULTRA** : Select this if inferior printing cannot be improved even by [HARD] cleaning.

**3** Press the **ENTER** key.

**4** Press **▲ ▼** to select the cleaning head, and press the **FUNC2** (✓) key.

- After selecting the head, press the [FUNC2] key and put a check in the check box. The head whose box has been checked will be cleaned.
- To have both head 1 and head 2 cleaned, put a check in both their check boxes.

**5** Press the **ENTER** key.

**6** Perform test printing again, and check the result.

- Repeat the cleaning and the test printing until the printing result becomes in normal.



**When the image quality is not improved after the head cleaning.**

- Clean the wiper and ink cap. (P.4-6)
- Wash the head nozzle. (P.4-7)

# Setting of Media Correction

Correct the media feed amount to match the type of media you are using.

If the correction value is not appropriate, stripes may appear on the printed image, thus resulting in a poor printing.




- On completion of [MEDIA COMP.] during use of a roll media, the media returns to the printing origin. Then the roll media in the rear of this machine will slacken. Before printing, take up the slack in the roll media by hand; a loose roll media can result in an inferior image quality.

## Setting of Media Correction

A pattern for media correction is printed and a media-feeding rate is corrected.



- Two bands are printed in the correction pattern.
- Make adjustment so that an even color density is obtained in the boundary between the two bands.



**1** Set a media. (P.2-4)

**2** Press the **SEL** key, and press the **FUNC2** (ADJUST) in LOCAL.

- ADJUST MENU will be displayed.

**3** Press the **ENTER** key twice to print the correction pattern

**4** Check the correction pattern and enter a correction value.


- A screen for entering the correction value will be displayed.
- **Enter a correction value in "+":**  
The boundary between the two bands is widened.
- **Enter a correction value in "-":**  
The boundary between the two bands is narrowed.
- When you change the correction value by "30", the width of the boundary changes by about 0.1 mm.

## If the Positions of Dots Shift...

When the condition for printing (media thickness/ink type/etc.) has been changed, perform the following operation to correct the ink drop position for bidirectional (Bi) printing and obtain the proper printing result.

- Important!**
- When using leaf media, set a media of more than A3 size put horizontally. If a media with narrow width is set, printing will only be conducted to midway.

### Example of a Printed Pattern




- Press the **SEL** key, and press the **FUNC1 (ADJUST)** in LOCAL.
  - ADJUST MENU will be displayed.
- Press **▼**, and press the **ENTER** key.
  - "DROP.POScorrect" will be selected.
- Press the **ENTER** key.
  - Printing of the Drop position correct printed pattern will start.
  - Multiple test patterns are printed. (The printed patterns are called Pattern 1, Pattern 2, Pattern 3... in the order of printing.)
- Press **▲ ▼** to enter a correction value of Pattern 1, and press the **ENTER** key.
  - Corrected feeding rate: -40 to 40
  - Check the test patterns. The position where an outward feeding line and a return feeding line become one straight line is the correction value.
  - When the correction value is not between -40 and 40, adjust the height of the printing heads and then perform the operations in Step 2 and later.
- In the same way as in Step 4, enter a correction value of Pattern 2 and later, and press the **ENTER** key.
- Press the **END/POWER** key several times to end the setting.

## Printing Data

### Starting a Printing Operation

- Important!**
- When using a roll media, rewind the media by hand before printing so that it is not loose. When the roll media has not been rewound tightly, it may cause the image quality to deteriorate.

#### 1 Setting a Media (P.2-4)




#### 2 Press the **FUNC3 (REMOTE)** key in LOCAL.

- The screen changes to REMOTE, and data can be received from the PC.

#### 3 Transmit data to be printed from the PC.

- The ACTIVE lamp blinks and the printing conditions are displayed.
- For the method of data transmission, see the instruction manual for the output software.



#### 4 Start printing.

- The printing speed may change, depending on the width of the set media or the position of the print origin even when the same data is printed. This is because of a difference in resolution.

## Stopping a Printing Operation

Perform the following operation when stopping a printing operation halfway.

- 1 Press the **FUNC3** (**LOCAL**) during printing.
  - The printing operation stops.
  - Interrupt data sending at the PC side during the data is sent from the PC.
  - Printing restarts from the interrupted data by repressing the **[REMOTE]** key.

## Deleting Received Data (Data Clear)


When you want to stop printing, delete the already received data.

- 1 Press the **SEL** key, and press the **FUNC3** (**DATA CLEAR**) in **LOCAL**.
- 2 Press the **ENTER** key.
  - The received data is erased then it returns to the Local.


## Cutting a media

By using the keys on the operation panel, you can cut the media at any position.

- 1 In Local, Press **▲** **▼** **◀** **▶**.
  - It enters into the origin setting mode.
  - By pressing **[▼]**, feed the media to the cutting position.



- 2 Press the **FUNC2** **ENTER** key.
  - The media is cut.
  - When the cutting has been completed, the current mode returns to LOCAL.





# Chapter 3

## Setup




### This chapter

describes various settings of this machine.

About SETUP MENU .....	3-2	Setting a KEY BUZZER .....	3-13
SETUP MENU table .....	3-3	Setting the CONFIRM. FEED .....	3-14
Register the optimal print conditions to match the use .....	3-4	Setting the SPACE FEED MODE .....	3-14
Setting of Media Correction .....	3-5	Set the network .....	3-14
If the Positions of Dots Shift .....	3-6	Setting event mail function .....	3-15
Setting of Logical Seek .....	3-6	Initializing the Settings .....	3-19
Setting of Drying Time .....	3-7	About INFORMATION MENU .....	3-20
Setting of Left and Right Margins .....	3-7	INFORMATION MENU table .....	3-21
Setting of Vacuum Fan .....	3-8	Displaying the Information .....	3-21
Setting of Feed Speed .....	3-8		
Setting of MAPS .....	3-8		
Setting Auto Cleaning .....	3-8		
Setting Interval wiping .....	3-9		
About MACHINE SETUP MENU .....	3-10		
MACHINE SETUP MENU table .....	3-11		
Setting a AUTO Power-off .....	3-12		
Setting the Display of Media Residual .....	3-12		
Setting a LANGUAGE .....	3-13		
Setting Time .....	3-13		
Setting Unit (Temperature/ Length) .....	3-13		


# About SETUP MENU

On SETUP MENU, you can set the print conditions to match the media you usually use.



- FUNC1** : Press this to select SETUP MENU, or to switch to the previous screen.
- FUNC3** : Press this to switch to the next screen.
- ▲ ▼** : Use these to select a setting item.
- ENTER** : Press this to confirm a setting, etc..

## ◆ SETUP MENUs at-a-glance





## SETUP MENU table



- For each setting item below, you can set it so that the machine may operate according to the value specified when you printed from your RIP software in the connected host PC.
- **Set Item** : DRYING TIME/ MARGIN (LEFT and RIGHT)/ VACUUM FAN/ FEED SPEED
- When you operate the machine according to the contents specified with the RIP software, set each item to "Host" when registering this machine type. When you set it other than "Host", the machine operates according to the machine setting.
- For the specifying method with the RIP software, refer to the operation manual of the RIP software.

Function name		Set value	When no instruction from RIP exists *1	Outline
FEED COMP. (P.3-5)		-9999 to 0 to 9999	_____	Used to print a pattern for correcting a media-feeding rate and correct it.
DROP.POScorrect (P.3-6)		-40.0 to 0 to 40.0	_____	Used to adjust the dot position in go and return printing.
LOGICAL SEEK (P.3-6)		HOST/ON / OFF	OFF	Sets the scan movable area during printing.
DRYING TIME (P.3-7)	SCAN	HOST/0.0 to 9.9 sec	0 sec	Sets the time to wait for ink drying.
	PRINT END	HOST/0 to 120 min	0 min	
MARGIN/LEFT (P.3-7)	MARGIN/RIGHT (P.3-7)	-10 to 85mm	0 mm	Sets a non-printing area along the right and left edges of the media.
			0 mm	
VACUUM FAN (P.3-8)		HOST/ WEAK/ STANDARD/ STRONG	STRONG	Sets the absorbability of the media.
FEED SPEED *2 (P.3-8)		10 to 100 to 200 %	100 %	Changes the media feeding speed in printing.
AUTO CLEANING (P.3-8)	OFF, FILE, LENGTH, TIME		_____	Sets the automatic cleaning operation for the head performed before printing or during printing.
	FILE INTERVAL TYPE	1 to 1000	_____	
		NORMAL/ SOFT/ HARD	_____	
	LENGTH INTERVAL TYPE	0.1 to 100.0m	_____	
		NORMAL/ SOFT/ HARD	_____	
	TIME INTERVAL TYPE	10 to 120 min	_____	
NORMAL/ SOFT/ HARD		_____		
Cleaning Check		ON/ OFF	_____	Set to run or not a nozzle check after auto cleaning.
INTERVAL WIPING (P.3-9)		3 to 255 min, OFF	_____	Sets the wiping operation performed after printing is completed.
EXTERNAL HEATER		ON/OFF	_____	Set to "ON" when use the external heater for drying the media. For more information, please refer to the separate manual, "Compact Relay BOX Operation Manual".
MAPS (P.3-8)	AUTO			Change the effect of "MAPS".
	MANUAL	Speed	50 ~ 100%	
		Smoothing level	0 ~ 100%	
RESET SETTING (P.3-5)		The configuration in the settings 1-4 can be reset individually.		

\*1. This is the setting value to be used for printing when setting value is not specified at the RIP software (host) side, or, you give priority to the setting value at the machine side.

\*2. When you set this to "100%" or more, required time for completion of printing will be shortened. However, enough drying time cannot be ensured and it may affect the image quality.

## Register the optimal print conditions to match the use

In this machine, you will be able to register print conditions, SETUP 1 to 4 individually to match the media in advance.

For example, after print on different types of media, return to the media always use. In such case you can set the optimum printing conditions by simply selecting the registered SETUP 1 to 4.



- Print conditions that can be pre-registered with the machine are the four types, "SETUP 1" to "SETUP 4".
- If you print with the print condition which do not often use, you will be able to set the print conditions by selecting "Temporary". If turn on the power again, settings in "Temporary" will return to the original state when it was purchased. Also if turn on the power again in "Temporary" state, it will be the state in selecting "SETUP 1".

## Register the print conditions to SETUP 1 to 4

- 1 Press the **FUNC1 (MENU)** → **ENTER** key in LOCAL.
- 2 Press **▲** **▼** to select SETUP 1 to 4, and press the **ENTER** key.
  - The item selected indicates ● and others show ○.
  - SETUP MENU will be displayed.
- 3 Press **▲** **▼** to select and set each item in the setup menu list.
  - Please see the reference page in the setup menu list for detailed configuration procedure.

## How to use [Temporary]

[Temporary] is not only to set the print condition to be used only once, but also can be used for partial change of the registered SETUP "1 to 4", or for reflecting the print conditions set by the [Temporary] to SETUP 1 to 4.

### ● Register the print conditions in [Temporary]

Registration of the print conditions to [Temporary] can be done as the same method as to SETUP 1 to 4.

- 1 Press the **FUNC1 (MENU)** → **ENTER** key in LOCAL.
- 2 Press **▲** **▼** to select "Temporary", and press the **ENTER** key.
  - SETUP MENU will be displayed.
- 3 Press **▲** **▼** to select and set each item in the setup menu list.
  - Please see the reference page in the setup menu list for detailed configuration procedure.

### ● Copy the contents of SETUP 1 to 4 to [Temporary]

You can use it with changing the part of registration contents of SETUP 1 to 4.

Select "RESET SETTING" then "COPY" from the registration screen of [Temporary], and specify the copy source (SETUP 1 to 4).

- 1 Press the **FUNC1 (MENU)** → **ENTER** key in LOCAL.
- 2 Press **▲** **▼** to select "Temporary", and press the **ENTER** key.
  - SETUP MENU will be displayed.
- 3 Press the **FUNC1 (<<)**.
- 4 Press **▲** **▼** to select "RESET SETTING", and press the **ENTER** key.
- 5 Press **▲** **▼** to select "COPY", and press the **ENTER** key.
  - Selection screen of the copy source will be displayed.
- 6 Press **▲** **▼** to SELECT the copy source (SETUP 1 to 4) and press the **ENTER** key.
  - Confirmation screen of the copy will be displayed.
- 7 Press the **ENTER** key.
  - Settings selected in step 5 is copied to Temporary.
- 8 Press **▲** **▼** to select the setting item to be changed, and press the **ENTER** key.
  - Please see the reference page in the setup menu list for detailed configuration procedure.

### ● Reflect The Content Set In [Temporary] To Setup 1 To 4

- 1 Press the **FUNC1 (MENU)** → **ENTER** key in LOCAL.
- 2 Press **▲** **▼** to select "Temporary", and press the **ENTER** key.
  - SETUP MENU will be displayed.
- 3 Press **▲** **▼** to select and set each item in the setup menu list.
  - Please see the reference page in the setup menu list for detailed configuration procedure.
- 4 Display the last page of Temporary and select "SAVE SETTING", and press the **ENTER** key.
  - Selection screen of the save location will be displayed.
- 5 Press **▲** **▼** to select the location selected (SETUP 1 to 4), and press the **ENTER** key.
  - Save confirmation screen will be displayed.

- 6** Press the **ENTER** key.
  - Settings of Temporary will be saved to the location selected in step 5.
- 7** Press the **END/POWER** key several times to end the setting.

### Reset the registered contents

Reset the contents registered to SETUP 1 to 4.

- 1** Press the **FUNC1** (MENU)  $\rightarrow$  **ENTER** key in LOCAL.
- 2** Press  $\uparrow$   $\downarrow$  to select **SETUP 1 to 4** to be reset and press the **ENTER** key.
  - SETUP MENU will be displayed.
- 3** Press the **FUNC1** (<<).
- 4** Press  $\uparrow$   $\downarrow$  to select **"RESET SETTING"**, and press the **ENTER** key.
  - Confirmation screen of reset settings will be displayed.
- 5** Press the **END/POWER** key several times to end the setting.

### Setting of Media Correction

Correct the media feed amount to match the type of media you are using.


If the correction value is not appropriate, stripes may appear on the printed image, thus resulting in a poor printing.

- Important!**
- On completion of [MEDIA COMP.] during use of a roll media, the media returns to the printing origin. Then the roll media in the rear of this machine will slacken. Before printing, take up the slack in the roll media by hand; a loose roll media can result in an inferior image quality.

A pattern for media correction is printed and a media-feeding rate is corrected.



- Two bands are printed in the correction pattern.
- Make adjustment so that an even color density is obtained in the boundary between the two bands.



- 1** Set a media. (👉 P.2-4)
- 2** Press the **FUNC1** (MENU)  $\rightarrow$  **ENTER** key in LOCAL.
- 3** Press  $\uparrow$   $\downarrow$  to select **SETUP 1 to 4**, and press the **ENTER** key.
  - SETUP MENU will be displayed.
- 4** Press  $\uparrow$   $\downarrow$  to select **"FEED COMP"**, and press the **ENTER** key.
- 5** Press **ENTER** the key twice to print a correction pattern.
- 6** Check the correction pattern and enter a correction value.
  - A screen for entering the correction value will be displayed.
  - Enter a correction value in "+":  
The boundary between the two bands is widened.
  - Enter a correction value in "-":  
The boundary between the two bands is narrowed.
  - When you change the correction value by "30", the width of the boundary changes by about 0.1 mm.
- 7** Press the **ENTER** key.
  - Print a correction pattern again and check it.
  - When media correction is needed, perform the operation in Step 6 to make correction.
- 8** Press the **END/POWER** key several times to end the setting.

### Correcting Media-feeding during Printing


A media-feeding rate can be corrected even in the remote mode or when image data is printed.

- 1** Press the **FUNC1** (ADJUST)  $\rightarrow$  **ENTER** key in the Remote.
- 2** Press  $\uparrow$   $\downarrow$  to enter a corrected feeding rate.
  - Corrected feeding rate: -9999 to 9999
  - The value entered here is reflected in the corrected feeding rate soon.
- 3** Press the **ENTER** twice key.
  - key. The changed value is registered.
  - When you press the [ENTER] key instead of the [END] key, the value entered here will be valid temporarily. (When you perform media detection again or turn the power OFF, the correction value is cleared.)

## If the Positions of Dots Shift...

When the condition for printing (media thickness/ink type/ etc.) has been changed, perform the following operation to correct the ink drop position for bidirectional (Bi) printing and obtain the proper printing result.

### Example of a Printed Pattern




- 1** Set a media on the machine. (P.2-4)
  - In order to print a pattern, a media that is 500 mm wide at least is necessary.
- 2** Press the **FUNC1** (MENU) → **ENTER** key in LOCAL.
- 3** Press **▲** **▼** to select **SETUP 1 to 4**, and press the **ENTER** key.
  - In order to print a pattern, a media that is 500 mm wide at least is necessary.
  - SETUP MENU will be displayed.
- 4** Press **▲** **▼** to select “**DROP.POS correct**”, and press the **ENTER** key.
- 5** Press the **ENTER** key.
  - Start the pattern printing.
  - Multiple test patterns are printed. (The printed patterns are called Pattern 1, Pattern 2, Pattern 3... in the order of printing.)
- 6** Press **▲** **▼** to enter a correction value of Pattern 1, and press the **ENTER** key.
  - Corrected feeding rate: -40 to 40
  - Check the test patterns. The position where an outward feeding line and a return feeding line become one straight line is the correction value.
  - When the correction value is not between -40 and 40, adjust the height of the printing heads and then perform the operations in Step 2 and later.
- 7** In the same way as in Step 4, enter a correction value of Pattern 2 and later, and press the **ENTER** key.
- 8** Press the **END/POWER** key several times to end the setting.


## Setting of Logical Seek

The head's operation varies depending on the LOGICAL SEEK settings, as shown in the figure below.

### Movement of heads when LOGICAL seek is OFF



### Movement of heads when LOGICAL seek is ON




- 1** Press the **FUNC1** (MENU) → **ENTER** key in LOCAL.
- 2** Press **▲** **▼** to select **SETUP 1 to 4**, and press the **ENTER** key.
  - SETUP MENU will be displayed.
- 3** Press **▲** **▼** to select “**LOGICAL SEEK**”, and press the **ENTER** key.
- 4** Press **▲** **▼** to select a set value, and press the **ENTER** key.
  - Set value : HOST / ON / OFF
- 5** Press the **END/POWER** key several times to end the setting.

## Setting of Drying Time

In the drying time setting, the following items for ink drying time are set.

- **SCAN** : Ink drying time for each scanning is set. (During bidirectional printing, the machine stops for a certain period of time specified for each of the outward and return scanning.)
- **PRINT END** : Ink drying time after printing has been complete is set.

-  • When you give priority to the setting at the RasterLink side, make the setting value "Host".
- "SCAN" set in this machine is displayed as "Pause Time per Scan" in the RasterLink.
  - You cannot specify the print end at the RasterLink side. When you set this machine to "Host", printing will be performed in "PRINT END= 0 min." status.

**1** Press the **FUNC1 (MENU)** → **ENTER** key in LOCAL.

**2** Press **▲** **▼** to select **SETUP 1 to 4**, and press the **ENTER** key.

- SETUP MENU will be displayed.

**3** Press **▲** **▼** to select **"DRYING TIME"**, and press the **ENTER** key.

**4** Press the **ENTER** key.

**5** Press **▲** **▼** **◀** **▶** to set drying time, and press the **ENTER** key.

- Set the drying time for canning and after printing is completed. To enable the drying time specified in your RIP, select "Host".
- **Scanning setting value** : Host or 0.0 sec. to 9.9 sec.
- **Print end setting value** : Host or 0 sec. to 120 min.
- **Item selecting** : by the **▲****▼** keys
- **Time setting** : by the **◀****▶** keys

**6** Press the **END/POWER** key several times to end the setting.

## Setting of Left and Right Margins

Set a non-printing area along the left and right edges of the media.

The offset value against the standard margin 15mm is set hereupon.



- When you give priority to the setting at the RIP software side, make the setting value "Host".
- You cannot specify the margins at the attached RIP software (RasterLink). When you use the RasterLink, if you set this machine to "Host", printing will be performed in "Margins for right and left off set value= 0 mm" status.
- The margin setting is reflected when the media width is detected.

**1** Press the **FUNC1 (MENU)** → **ENTER** key in LOCAL.

**2** Press **▲** **▼** to select **SETUP 1 to 4**, and press the **ENTER** key.

- SETUP MENU will be displayed.

**3** Press **▲** **▼** to select **"Margin/L"** or **"Margin/R"**, and press the **ENTER** key.

**4** Press **▲** **▼** to select a set value, and press the **ENTER** key.

- Set value : HOST / -10 to 85 mm

**5** Press the **END/POWER** key several times to end the setting.



- Pay attention to that printing may start on the media press if a right and left margin is set to 5 mm or less when the media press is used in printing.

## Setting of Vacuum Fan

Sets the absorbability of the media.

By setting the absorption power to match the media, you can prevent print errors due to media rise-up.

- 1 Press the **FUNC1 (MENU)** ➔ **ENTER** key in LOCAL.
- 2 Press **▲** **▼** to select **SETUP 1 to 4**, and press the **ENTER** key.
  - SETUP MENU will be displayed.
- 3 Press the **FUNC3 (>>)**.
- 4 Press **▲** **▼** to select **“VACUUM FAN”**, and press the **ENTER** key.
- 5 Press the **ENTER** key.
- 6 Press **▲** **▼** to select a set value, and press the **ENTER** key.
  - Set value : HOST/WEAK /STANDARD/ STRONG
- 7 Press the **END/POWER** key several times to end the setting.

## Setting of Feed Speed

Changes the media feeding speed in printing.

- 1 Press the **FUNC1 (MENU)** ➔ **ENTER** key in LOCAL.
- 2 Press **▲** **▼** to select **SETUP 1 to 4**, and press the **ENTER** key.
  - SETUP MENU will be displayed.
- 3 Press the **FUNC3 (>>)**.
- 4 Press **▲** **▼** to select **“FEED SPEED”**, and press the **ENTER** key.
- 5 Press the **ENTER** key.
- 6 Press **▲** **▼** to select a set value, and press the **ENTER** key.
  - Set value : HOST / 10 to 200%
- 7 Press the **END/POWER** key several times to end the setting.

## Setting of MAPS

The MAPS (Mimaki Advanced PassSystem) function to disperse the pass boundary to make the feeding stripes less visible.

With this function, the degree of application of MAPS can be changed.



- MAPS provides two setting options: “AUTO” and “MANUAL” MAPS applies the one most suitable for your printing conditions, so please normally use “AUTO” (default value).
- In order to use this function, Mimaki driver Ver 4.2.0 or higher is required.



- Changing the MAPS settings may change the color tone. Check the effects before use.
- MAPS may not be effective depending on image to be printed. Use it after checking effect in advance.

## Setting Auto Cleaning

You can set the machine so that it counts the number of printed files or the length or time after printing has been completed, and performs cleaning automatically if required. You can select the auto cleaning setting from three types below:

- PAGE : Set the cleaning intervals by the number of printed files.
- LENGTH : Set the cleaning intervals by the printed length.
- TIME : Set the cleaning intervals by the printed time.

Besides, automatic nozzle check after auto cleaning can be set. (Cleaning Check function)

The machine can perform a stable printing operation with its heads always kept clean.

- 1 Press the **FUNC1 (MENU)** ➔ **ENTER** key in LOCAL.
- 2 Press **▲** **▼** to select **SETUP 1 to 4**, and press the **ENTER** key.
  - SETUP MENU will be displayed.
- 3 Press the **FUNC3 (>>)**.
- 4 Press **▲** **▼** to select **“AUTO CLEANING”**, and press the **ENTER** key.

**5** Press **ENTER** key, and press **▲** **▼** to select the type of auto cleaning.

- There are "PAGE", "LENGTH" and "TIME" for auto cleaning.

**FILE:** When the set number of prints has been completed, the machine performs head cleaning automatically.

**LENGTH:** When the set length has passed, the machine performs head cleaning automatically.

**TIME:** When the set time has passed, the machine performs head cleaning automatically.

- If you do not set auto cleaning, first select "OFF" and then proceed to the Step 7.

**6** Press **ENTER** key, and press **▲** **▼** to select the cleaning interval.

- Depending on the auto cleaning type selected in the Step 3, the setting value differs.

For **FILE** : 1 to 1000 file

For **LENGTH** : 0.1 to 100.0m (in 0.1m increment)

For **TIME** : 10 to 120min (in 10min increment)

**7** Press **ENTER** key, and press **▲** **▼** to select the cleaning type.

- Set Value : NORMAL/ SOFT/HARD

**8** Press **ENTER** key, and press **▲** **▼** to select "Cleaning Check".

**9** Press **ENTER** key, and press **▲** **▼** to select set value.

- Set Value : ON/ OFF

**10** Press the **ENTER** key.

**11** Press the **END/POWER** key several times to end the setting.

**Important!**

- Depending on the state of the heads, etc., the image quality deterioration may not be improved even with this function performed. In this case, contact our service office or the distributor in your region.

## Setting Interval wiping

When the set time has passed, nozzle face of the head is cleaned automatically to remove ink droplets on the nozzle face.

In case that deflection, nozzle missing, or symptom which ink droplets fall down occurred, set the interval between each operation shorter.

**1** Press the **FUNC1 (MENU)** **▶** **ENTER** key in **LOCAL**.

**2** Press **▲** **▼** to select **SETUP 1 to 4**, and press the **ENTER** key.

- SETUP MENU will be displayed.

**3** Press the **FUNC3 (>>)**.

**4** Press **▲** **▼** to select "INTERVAL WIPING", and press the **ENTER** key.

**5** Press **▲** **▼** to set intervals.


- Set Value : 3 to 255 Minutes, OFF
- When [OFF] is set, periodical wiping is not executed.

**6** Press the **ENTER** key.

**7** Press the **END/POWER** key several times to end the setting.

# About MACHINE SETUP MENU

Common settings are functions for using this machine easily.  
The following items can be set in Machine settings.



- FUNC1** : Press this to select MACHINE SETUP MENU, or to switch to the previous screen.
- FUNC3** : Press this to switch to the next screen.
- ▲ ▼** : Use these to select a setting item.
- ENTER** : Press this to confirm a setting, etc..

## ◆ MACHINE SETUP MENUS at-a-glance

The sequence of screenshots illustrates the following steps:

- LOCAL** screen: Press **FUNC1** (twice) to enter the **MENU** screen.
- MENU** screen: Press **ENTER** to select **MACHINE SETUP**.
- MACHINE SETUP** screen: Press **ENTER** to confirm the selection.
- MACHINE SETUP** screen: Press **▲ ▼** to navigate to **AUTO POWER OFF** (30min).
- MACHINE SETUP** screen: Press **▲ ▼** to navigate to **Drying/Exhaust FAN**.
- MACHINE SETUP** screen: Press **▲ ▼** to navigate to **MEDIA REMAIN** (OFF).
- MACHINE SETUP** screen: Press **▲ ▼** to navigate to **LANGAGE**.
- MACHINE SETUP** screen: Press **▲ ▼** to navigate to **TIME**.
- MACHINE SETUP** screen: Press **▲ ▼** to navigate to **UNIT/TEMP.** (°C).
- MACHINE SETUP** screen: Press **▲ ▼** to navigate to **UNIT/LENGTH** (mm).
- MACHINE SETUP** screen: Press **▲ ▼** to navigate to **KEY BUZZER** (ON).
- MACHINE SETUP** screen: Press **▲ ▼** to navigate to **CONFIRM. FEED** (ON).
- MACHINE SETUP** screen: Press **▲ ▼** to navigate to **SPACE FEED MODE**.
- MACHINE SETUP** screen: Press **▲ ▼** to navigate to **NETWORK**.
- MACHINE SETUP** screen: Press **▲ ▼** to navigate to **EVENT MAIL**.
- MACHINE SETUP** screen: Press **▲ ▼** to navigate to **RESET**.



## MACHINE SETUP MENU table

Function name	Set value	Default	Meaning		
AUTO Power-off (P.3-12)	NONE/ 10 ~ 600min	30min	When no operation has been performed for the set time, the power supply is automatically turned "OFF".		
Drying/Exhaust FAN	Set when use the optional Drying / exhaust fan. For more information, please refer to the instruction manual that came with the Drying/exhaust fan.				
MEDIA REMAIN (P.3-12)	ON/ OFF	OFF	You can control the remaining amount of media.		
LANGUAGE (P.3-13)		English	Displayed language is changed.		
TIME (P.3-13)	+4h ~ -20h	Japan time	Time difference is corrected.		
UNIT/ TEMP. (P.3-13)	°C (Centigrade)/°F (Fahrenheit)	°C	A unit for displaying temperature is set.		
UNIT/ LENGTH (P.3-13)	mm / inch	mm	A unit for displaying length and area is set.		
KEY BUZZER (P.3-13)	OFF / ON	ON	A buzzer sound when keys are pressed is set.		
CONFIRM. FEED (P.3-14)	ON / OFF	ON	Set whether media feeding is performed for checking the result of the test printing etc. or not.		
SPACE FEED MODE (P.3-14)	INTERMITTENT / CONTINUOUS	INTERMI TTENT	Change the feed mode of the margin included in the image data.		
NETWORK (P.3-14)	Set the network.				
	Check IP Addr.	The IP address currently used by this machine is displayed.			
	Check MAC Addr.	The IP address currently used by this machine is displayed.			
	DHCP	ON / OFF	When it is ON, the IP address given by the DHCP server is used.		
	AutoIP	ON / OFF	When it is ON, the IP address is determined by the AutoIP protocol. However, DHCP is ON, DHCP has priority.		
	IP Address *1	Set the IP address used by this machine.			
	Default Gateway *1	Set the default gateway used by this machine.			
	DNS Address *1	Set the DNS server address used by this machine.			
	SubNet Mask *1	Set the digit number of the subnet mask used by this machine.			
EVENT MAIL	Mail Delivery (P.3-15)	ON / OFF	OFF	Set whether you send/ do not send the e-mail when the set event occurs.	
	Select Event (P.3-16)	Print Start Event	ON / OFF	OFF	Set whether you send/ do not send the e-mail at the start of printing.
		Print End Event	ON / OFF	OFF	Set whether you send/ do not send the e-mail at the end of printing.
		Error Event	ON / OFF	OFF	Set whether you send/ do not send the e-mail when a error occurs.
		Warning Event	ON / OFF	OFF	Set whether you send/ do not send the e-mail when a warning occurs.
		Other Event	ON / OFF	OFF	Set whether you send/ do not send the e-mail when an event other than the above occurs.
	Mail Address (P.3-16)	Set the e-mail address to which you send the event mail.	Alphanumeric characters and symbols (within 96 characters)		
	Message Subject (P.3-16)	Set the characters to write in the subject of the event mail.	Alphanumeric characters and symbols (within 8 characters)		
	Server Setup (P.3-17)	SMTP Address		Set the SMTP server.	
		SMTP Port No.		Set the SMTP port number.	
SENDER ADDRESS		Set the e-mail address to be used as the sender mail address.			

Function name		Set value		Default	Meaning
EVENT MAIL	Server Setup ( P.3-17)	Authentication	POP before SMTP		Set the SMTP server authentication method (SMTP authentication).
			SMTP Authentication		
			OFF		
		User Name *2	Set the user name used for the authentication.		
		Pass Word *2	Set the password used for the authentication.		
	POP3 Address *3	Set the POP server.			
	APOP *3	Set ON/ OFF of APOP.			
	Transmit Test ( P.3-18)	Send the test e-mail.			
RESET( P.3-19)					All setting values are returned to the status default.

\*1. Settable when both of DHCP and AutoIP are [OFF]

\*2. Settable only when Auth. is not OFF

\*3. Settable only when Auth. is POP before SMTP

### Setting a AUTO Power-off

When no operation has been performed for the set time, the power supply is automatically turned "OFF".

- 1 Press the **FUNC1 (MENU)** (twice) **ENTER** key in LOCAL.
  - MACHINE SETUP MENU will be displayed.
- 2 Press to select "AUTO POWER OFF", and press the **ENTER** key.
- 3 Press to select a set value, and press the **ENTER** key.
  - Set Value : none, 10 to 600min
- 4 Press the **END/POWER** key several times to end the setting.

### Setting the Display of Media Residual

Whether the screen displays the remaining amount of a media is set.

When the media remaining amount display is turned to "ON"	the remaining amount of a media is displayed in Remote. (However, when a leaf media is used, the length of the media to be printed is displayed.)
When the media remaining amount display is turned to "OFF"	the remaining amount of a media is not displayed in the Remote.



- The amount of a media that has been fed by the printing and jog keys is reflected in the remaining amount of a media.
- The length of a media (initial value of the remaining amount) is entered when a roll media is detected. ( P.2-7)
- The setting configured here does not become effective unless media detection is performed after the setting has been complete.

- 1 Press the **FUNC1 (MENU)** (twice) **ENTER** key in LOCAL.
  - MACHINE SETUP MENU will be displayed.
- 2 Press to select "MEDIA REMAIN", and press the **ENTER** key.
- 3 Press to select ON/OFF.
- 4 Press the **ENTER** key.
- 5 Press the **END/POWER** key several times to end the setting.



- When set "ON" the media remaining display, you can print the list of current media remaining amount and the date. ( P.2-7)

## Setting a LANGUAGE

You can change the displayed language.

- 1 Press the **FUNC1** (MENU)  $\rightarrow$   $\downarrow$  (twice)  $\rightarrow$  **ENTER** key in LOCAL.
  - MACHINE SETUP MENU will be displayed.
- 2 Press  $\uparrow$   $\downarrow$  to select "LANGUAGE", and press the **ENTER** key.
- 3 Press  $\uparrow$   $\downarrow$  to select language, and press the **ENTER** key.
- 4 Press the **END/POWER** key several times to end the setting.

## Setting Time

You can set time of your country (time difference).

- 1 Press the **FUNC1** (MENU)  $\rightarrow$   $\downarrow$  (twice)  $\rightarrow$  **ENTER** key in LOCAL.
  - MACHINE SETUP MENU will be displayed.
- 2 Press  $\uparrow$   $\downarrow$  to select "TIME", and press the **ENTER** key.
- 3 Press  $\uparrow$   $\downarrow$   $\leftarrow$   $\rightarrow$  to enter time, and press the **ENTER** key.
  - Year/Month/Day/Time selecting: by the [ $\leftarrow$ ][ $\rightarrow$ ] keys.
  - Year/Month/Day/Time inputting: by the [ $\uparrow$ ][ $\downarrow$ ] keys.
- 4 Press the **END/POWER** key several times to end the setting.



- -20 hours to +4 hours can be set.

## Setting Unit (Temperature/ Length)

Units used by this machine are set.

- 1 Press the **FUNC1** (MENU)  $\rightarrow$   $\downarrow$  (twice)  $\rightarrow$  **ENTER** key in LOCAL.
  - MACHINE SETUP MENU will be displayed.
- 2 Press the **FUNC3** (>>) .
- 3 Press  $\uparrow$   $\downarrow$  to select "UNIT/TEMP." or "UNIT/LENGTH", and press the **ENTER** key.
  - MACHINE SETUP MENU will be displayed.
- 4 Press  $\uparrow$   $\downarrow$  to select a set value, and press the **ENTER** key.
  - Set value of temperture : °C / °F
  - Set value of length : mm / inch
- 5 Press the **END/POWER** key several times to end the setting.

## Setting a KEY BUZZER

You can turn off the buzzer sound when pressing the key.

- 1 Press the **FUNC1** (MENU)  $\rightarrow$   $\downarrow$  (twice)  $\rightarrow$  **ENTER** key in LOCAL.
  - MACHINE SETUP MENU will be displayed.
- 2 Press the **FUNC3** (>>) .
- 3 Press  $\uparrow$   $\downarrow$  to select "KEY BUZZER", and press the **ENTER** key.
- 4 Press  $\uparrow$   $\downarrow$  to select a set value, and press the **ENTER** key.
  - Set value : ON/ OFF
- 5 Press the **END/POWER** key several times to end the setting.



- When the key buzzer is set to "OFF", the buzzer sound for errors, warnings, operation completion, etc. cannot be shut off.

## Setting the CONFIRM. FEED

Set whether media feeding is performed for checking the result of the test printing etc. or not.

- 1 Press the **FUNC1 (MENU)**  $\rightarrow$  **▼** (twice)  $\rightarrow$  **ENTER** key in LOCAL.
  - MACHINE SETUP MENU will be displayed.
- 2 Press the **FUNC3 (>>)** .
- 3 Press **▲** **▼** to select "CONFIRM. FEED", and press the **ENTER** key.
- 4 Press **▲** **▼** to select a set value, and press the **ENTER** key.
  - Set value : ON/ OFF
- 5 Press the **END/POWER** key several times to end the setting.

## Setting the SPACE FEED MODE

Change the feed mode of the margin included in the image data (the space of no data to be printed). If print data with much margin, set to "continuous", then the print time can be shorten.

- 1 Press the **FUNC1 (MENU)**  $\rightarrow$  **▼** (twice)  $\rightarrow$  **ENTER** key in LOCAL.
  - MACHINE SETUP MENU will be displayed.
- 2 Press the **FUNC3 (>>)** .
- 3 Press **▲** **▼** to select "SPACE FEED MODE", and press the **ENTER** key.
- 4 Press **▲** **▼** to select a set value, and press the **ENTER** key.
 


INTERMITTENT : Perform intermittent feed operation of the path division unit

CONTINUOUS : Feed the no data part at a time
- 5 Press the **END/POWER** key several times to end the setting.

## Set the network

You can also perform network setting with "Network Configurator", the tool to perform network setting of Mimaki's product. To download the Network Configurator, check "Driver / Utility" on the download page at Mimaki Engineering (<http://eng.mimaki.co.jp/download/>).

- 1 Press the **FUNC1 (MENU)**  $\rightarrow$  **▼** (twice times)  $\rightarrow$  **ENTER** key in LOCAL.
  - MACHINE SETUP MENU will be displayed.
- 2 Press the **FUNC3 (>>)** .
- 3 Press **▲** **▼** to select "NETWORK", and press the **ENTER** key.
- 4 Press the **ENTER** key.
  - "CHECK IP ADDRESS" will be selected.
  - The IP address currently used by this machine is displayed.
  - When you have finished the check, press the [ENTER] key.

 • After connecting with the network, it takes time until the IP address is determined. If the IP address has not been determined, "0.0.0.0" is displayed.
- 5 Press **▼**, and press the **ENTER** key.
  - "CHECK MAC ADDRESS" will be selected.
  - The MAC address currently used by this machine is displayed.
  - When you have finished the check, press the [ENTER] key.
- 6 Press **▼**, and press the **ENTER** key.
  - "DHCP" will be selected.
- 7 Press **▲** **▼** to select a set value, and press the **ENTER** key.
  - Set value : ON/ OFF
  - When it is ON, the IP address given by the DHCP server is used.
- 8 Press **▼**, and press the **ENTER** key.
  - "AutoIP" will be selected.
- 9 Press **▲** **▼** to select a set value, and press the **ENTER** key.
  - Set value : ON/ OFF
  - When it is ON, the IP address is determined by the AutoIP protocol. However, DHCP is ON, DHCP has priority.
- 10 Press **▼**, and press the **ENTER** key.
  - "IP ADDRESS" will be selected.
- 11 Press **▲** **▼** to select a set value, and press the **ENTER** key.
  - Set value : ON/ OFF
  - Both of DHCP and AutoIP is OFF, you can set IP Address. For other than above, proceed to the Step 14.

12

Press the **FUNC3** key .

- The setting items DEFAULT GATEWAY, DNS ADDRESS and SUBNET MASK will be displayed.
- Both of DHCP and AutoIP is OFF, you can set DEFAULT GATEWAY/ DNS ADDRESS/ SUBNET MASK. For other than above, proceed to the Step 14.

13

Press the **▼** several times to select setting item, and press the **ENTER** key.

14

Press **▲** **▼** to select a set value, and press the **ENTER** key.

15

Press the **END/POWER** key several times to end the setting.



- To reflect network setting, once turn off the power supply and then turn it on again.

## Setting event mail function

Set the function to send e-mails to the set e-mail address when events such as cutting start/ end and stop due to an error.

You can also perform network setting with "Network Configurator", the tool to perform network setting of Mimaki's product. To download the Network Configurator, check " Driver / Utility" on the download page at Mimaki Engineering (<http://eng.mimaki.co.jp/download/>).

- Disclaimer
- The customer is responsible for the communication fee for Internet communication such as e-mail notification.
- The notification by the event mail function may not be delivered due to Internet environment, failure of the device/ the power supply, etc. Mimaki has absolutely no responsibility for any damages or loss resulting from non-delivery or delays.

**Important!**

- You can use event mail function by connecting LAN to this machine. Please prepare for LAN cable connection beforehand.
- Not compatible with SSL communication.

## Enable the event mail function

1

Press the **FUNC1** (MENU) **→** **▼** (twice times) **→** **ENTER** key in LOCAL.

- MACHINE SETUP MENU will be displayed.

2

Press the **FUNC1** (>>) .

3

Press **▲** **▼** to select "EVENT MAIL", and press the **ENTER** key.

4

Press the **ENTER** key.

- "MAIL DELIVERY" will be selected.

5

Press **▲** **▼** to select "ON", and press the **ENTER** key.

6

Press the **END/POWER** key several times to end the setting.

## Set the event to send an event mail

- 1 Press the **FUNC1** (MENU)  $\Rightarrow$  **▼** (twice times)  $\Rightarrow$  **ENTER** key in LOCAL.
  - MACHINE SETUP MENU will be displayed.
- 2 Press the **FUNC1** (>>) .
- 3 Press **▲** **▼** to select “EVENT MAIL”, and press the **ENTER** key.
- 4 Press **▼**, and press the **ENTER** key.
  - “SELECT EVENT” will be selected.
- 5 Press **▲** **▼** to select the event, and press the **FUNC2** (✓).
  - After selecting the event, press the [FUNC2] key and put a check in the check box. An email will be sent when the event whose box has been checked occurs.
  - To select multiple events, use [**▲**][**▼**] to put the cursor over the events you want, and put a check in their boxes by pressing [FUNC2].

Event name	Outline
PRINT START	Sets sending/not sending of an email when printing starts.
PRINT END	Sets sending/not sending of an email when printing ends.
ERROR	Sets sending/not sending of an email when printing is stopped due to occurrence of an error.
WARNING	Sets sending/not sending of an email when a warning occurs during printing.
etc.	Sets sending/not sending of an email when an event other than the above occurs.

- 6 Press the **END/POWER** key several times to end the setting.



























## Set the e-mail address























- 1 Press the **FUNC1** (MENU)  $\Rightarrow$  **▼** (twice times)  $\Rightarrow$  **ENTER** key in LOCAL.
  - MACHINE SETUP MENU will be displayed.
- 2 Press the **FUNC1** (>>) .
- 3 Press **▲** **▼** to select “EVENT MAIL”, and press the **ENTER** key.
- 4 Press **▼** twice, and press the **ENTER** key.
  - “MAIL ADDRESS” will be selected.
- 5 Press **▲** **▼** **◀** **▶** to set mail address, and press the **ENTER** key.
  - Set the e-mail address to which you send the event mail.
  - Set it with alphanumeric characters and symbols within 96 characters.
- 6 Press the **END/POWER** key several times to end the setting.


## Set the subject













- 1 Press the **FUNC1** (MENU)  $\Rightarrow$  **▼** (twice times)  $\Rightarrow$  **ENTER** key in LOCAL.
  - MACHINE SETUP MENU will be displayed.
- 2 Press the **FUNC1** (>>) .
- 3 Press **▲** **▼** to select “EVENT MAIL”, and press the **ENTER** key.
- 4 Press **▼** 3 times, and press the **ENTER** key.
  - “MESSAGE SUBJECT” will be selected.
- 5 Press **▲** **▼** **◀** **▶** to set subject, and press the **ENTER** key.
  - Set the characters to write in the subject of the event mail.
  - Set it with alphanumeric characters and symbols within 8 characters.
- 6 Press the **END/POWER** key several times to end the setting.

## Set the server

- 1 Press the **FUNC1** (MENU)   (twice times)  **ENTER** key in LOCAL.
    - MACHINE SETUP MENU will be displayed.
  - 2 Press the **FUNC1** (>>) .
  - 3 Press   to select “EVENT MAIL”, and press the **ENTER** key.
  - 4 Press  4 times, and press the **ENTER** key.
    - “SERVER SETUP” will be selected.
  - 5 Press the **ENTER** key.
    - “SMTP ADDRESS” will be selected.
  - 6 Press     to set SMTP Address, and press the **ENTER** key.
    - Press the jog key [][][][] to set SMTP address.
    - Input the SMTP address name.
  - 7 Press  , and press the **ENTER** key.
    - “SMTP PORT No.” will be selected.
  - 8 Press   to set SMTP Port No., and press the **ENTER** key.
    - Set the SMTP port number.
  - 9 Press  , and press the **ENTER** key.
    - “SENDER ADDRESS” will be selected.
- 10 Press     to set SENDER ADDRESS, and press the **ENTER** key.
    - Press [][][][] and set the e-mail address to be used as the sender mail address.
    - Set it with alphanumeric characters and symbols within 64 characters.


    - Depending on your server, if you do not set the e-mail address not supporting the account, sending/ receiving e-mails may be unavailable.
  - 11 Press  , and press the **ENTER** key.
    - “AUTHENTICATION” will be selected.
  - 12 Press   to set authentication method, and press the **ENTER** key.
    - Set the authentication method of the SMTP server.
    - When you select [OFF], proceed to the Step 20.
  - 13 Press  , and press the **ENTER** key.
    - “USER NAME” will be selected.
  - 14 Press     to set User Name, and press the **ENTER** key.
    - Press [][][][] to set the user name to use for the authentication.
    - Set it with alphanumeric characters and symbols within 30 characters.
  - 15 Press  , and press the **ENTER** key.
    - “PASSWORD” will be selected.
  - 16 Press     to set Password, and press the **ENTER** key.
    - Press [][][][] to set the password to use for the authentication.
    - Set it with alphanumeric characters and symbols within 15 characters.



    - On the password setting screen, you can only check the value that you are currently inputting.

    - When you select [POP before SMTP] in the Step 11, set the items in the Step 16 to 19.
  - 17 Press  , and press the **ENTER** key.
    - “POP3 ADDRESS” will be selected.
  - 18 Press     to set POP3 Address, and press the **ENTER** key.
    - Press [][][][] to set POP server.
    - Input the POP server name.
  - 19 Press  , and press the **ENTER** key.
    - “APOPOP” will be selected.
  - 20 Press   to set ON/ OFF, and press the **ENTER** key.
  - 21 Press the **END/POWER** key several times to end the setting.

### Send a test e-mail

- 1** Press the **FUNC1 (MENU)** (twice times) → **ENTER** key in LOCAL.
  - MACHINE SETUP MENU will be displayed.
- 2** Press the **FUNC1 (>>)**.
- 3** Press **▲ ▼** to select “EVENT MAIL”, and press the **ENTER** key.
- 4** Press the **FUNC3 (>>)** → **ENTER** key.
  - “TRANSMIT TEST” will be selected.

- 5** Press the **ENTER** key.
  - The sent result is displayed.
  - If sending test e-mail has failed, an error code is displayed.  
Refer to the next page to solve the problem.



- 6** Press the **END/POWER** key several times to end the setting.



- The sent result of the test e-mail is the result of e-mail sending process performed by this machine to the e-mail server. It does not indicate that the e-mail was received at the address.
- If the spam e-mail filter etc. has been set in the terminal in which e-mails are received, even if “Sending has been completed” is displayed, the e-mail cannot be received in some cases.
- If sending test e-mail has failed, the error code below is displayed.
- If the error cannot be solved, try again after a while.
- For the server setting etc., contact with the network administrator or the provider.



Error Code	The expected casus	Remedy
10	Network connection error	<ul style="list-style-type: none"> <li>• Check that the machine is connected with the network.</li> <li>• Check that the machine IP address is correct.</li> <li>• Check that the machine is in the environment where DNS is available.</li> </ul>
20	No valid e-mail address.	<ul style="list-style-type: none"> <li>• Enter the correct e-mail address.</li> </ul>
11003 11004	The POP server cannot be found. Or cannot access DNS server.	<ul style="list-style-type: none"> <li>• Check the POP server address.</li> <li>• Check that the machine is in the environment where DNS is available.</li> </ul>
11021	Cannot connect with the POP server.	<ul style="list-style-type: none"> <li>• Check the POP server setting.</li> <li>• Check the firewall setting.</li> </ul>
12010	An error returns from the POP server.	<ul style="list-style-type: none"> <li>• Check the POP server setting.</li> </ul>
13000	The POP authentication has failed.	<ul style="list-style-type: none"> <li>• Check the user name and the password.</li> <li>• Check the APOP setting.</li> <li>• Confirm the authentication method.</li> </ul>
10013 10014	The SMTP server cannot be found. Or cannot access DNS server.	<ul style="list-style-type: none"> <li>• Check the SMTP server address.</li> <li>• Check that the machine is in the environment where DNS is available.</li> </ul>
10021	Cannot connect with the SMTP server.	<ul style="list-style-type: none"> <li>• Check the SMTP server setting.</li> <li>• Check the SMTP port number.</li> <li>• Check the firewall setting.</li> </ul>
10*** 11*** 20*** 21***	An error returns from the SMTP server. Or, there was no response.	<ul style="list-style-type: none"> <li>• Check the SMTP server setting.</li> <li>• Cannot communicate with a server that requires mandatory SSL communication.</li> <li>• Check protocol filter settings.</li> </ul>
12***	It is invalid sender address.	<ul style="list-style-type: none"> <li>• Check that the e-mail address supporting the account entered in the user name/ the password is set in SENDER ADDRESS.</li> </ul>
13***	The e-mail address cannot be found. Or, it is invalid sender address.	<ul style="list-style-type: none"> <li>• Check the e-mail address.</li> <li>• Even if there is a mistake in the e-mail address, this error cannot be detected in some cases.</li> <li>• Check that the e-mail address supporting the account entered in the user name/ the password is set in SENDER ADDRESS.</li> </ul>
22000 22008	SMTP authentication error	<ul style="list-style-type: none"> <li>• Confirm the authentication method.</li> </ul>
23*** 24*** 25***	The SMTP authentication has failed.	<ul style="list-style-type: none"> <li>• Check the user name and the password.</li> </ul>

“\*\*\*” is the error code returned from the e-mail server.




## Initializing the Settings

You can return the setting of “SETUP”, “MAINTENANCE” and “MACHINE SETUP” to the status before shipment.

- 1** Press the **FUNC1 (MENU)**  **▼** (twice)  **ENTER** key in **LOCAL**.
  - MACHINE SETUP MENU will be displayed.
- 2** Press the **FUNC1 (>>)** .
- 3** Press **▲** **▼** to select “RESET”, and press the **ENTER** key.
- 4** Press the **ENTER** key.
  - The already configured settings are initialized.
- 5** Press the **END/POWER** key several times to end the setting.

# About INFORMATION MENU

The information of this machine can be confirmed.  
 The following items can be confirmed as machine information.



- FUNC1** : Press this to select INFORMATION MENU, or to switch to the previous screen.
- FUNC3** : Press this to switch to the next screen.
- ▲ ▼** : Use these to select a setting item.
- ENTER** : Press this to confirm a setting, etc..



## INFORMATION MENU table

Item		Description
USAGE	WIPING	This displays how many wipings have been done.
	WASTE TANK	This displays how much waste ink has built up in the waste ink tank, as a rough percentage of the tank capacity.
	PRINT LENGTH	This displays the total length of the printing done to date.
	PRINT AREA	This displays the total area of the printing done to date.
	USE TIME	This displays the total time for which the printer has been used to date.
	Spout Rubber	This displays the total time for which Spout Rubber has been used. (Only displayed when MBIS is used)
VERSION		This displays the version information of this machine.
LIST		This allows you to print the settings of this machine.
Ink REPL. Report		This prints ink history of this machine.
ERROR HISTORY		This displays the history of errors and warnings to date. When you press [▲][▼], the date of occurrence (year/month/day/hour/minute) and the error/warning information are displayed alternately in the order of occurrence.

## Displaying the Information

**1** Press the **[FUNC1] (MENU) → [▼] (3 times) → [ENTER]** key in LOCAL.

- INFORMATION MENU will be displayed.

**2** Press **[▲] [▼]** to select a information.

- Refer to the "INFORMATION MENU", and select the information to be displayed.

**3** Press the **[ENTER]** key.

- If you selected [LIST] in step 2, the machine's settings will be printed.

**4** Press the **[END/POWER]** key several times to end the setting.



- When you reset the used count of the wiper, press the [FUNC2] key while [RESET?] is displayed. When you press the [ENTER] key, the number of wipings is reset.
- By pressing the function key during display of "WIPING information," "WASTE TANK information" and "Spout Rubber" in USAGE, the used counts can be reset.

**When resetting WIPING information** : Press the [FUNC2]  
**When resetting WASTE TANK information** : Press the [FUNC1]  
**When resetting Spout Rubber** : Press the [FUNC3]



# Chapter 4

## Maintenance



### This chapter

describes the items required to use this machine more comfortably, which are the methods for the daily care, the maintenance of the ink cartridges etc.






Maintenance .....	4-2	Automatic Maintenance Function .....	4-11
Precautions for Maintenance .....	4-2	Setting the Refreshing Intervals .....	4-11
About Cleaning Solution.....	4-2	Setting the Cleaning Intervals and Type ....	4-12
Cleaning the Exterior Surfaces .....	4-2	Fill up Ink .....	4-12
Cleaning the Platen .....	4-2	Replacing consumables .....	4-13
Cleaning the Media Sensor .....	4-3	Replacing the wiper .....	4-13
Cleaning the Media Press .....	4-3	If a Waste Ink Tank Confirmation Message	
About MAINTENANCE MENU .....	4-4	Appears .....	4-13
MAINTENANCE MENUs at-a-glance .....	4-5	Replacing the waste ink tank before the waste ink	
Maintaining the Capping Station .....	4-6	tank confirmation message is displayed .....	4-15
Cleaning the Wiper and Cap .....	4-6	Replacing the Cutter Blade .....	4-15
Washing the Head Nozzle .....	4-7		
Washing the Ink Discharge Passage .....	4-8		
When the Machine Is Not Used for a			
Long Time .....	4-8		
Cleaning the Ink Head and the Area			
around It .....	4-10		

# Maintenance

Maintain the machine regularly or as necessary so that its accuracy will be maintained and it can continue to be used for a long time.

## Precautions for Maintenance

Pay attention to the following items when maintaining this machine.

	<ul style="list-style-type: none"> <li>When using cleaning solution for maintenance, be sure to wear the supplied protective glasses.</li> </ul>
	<ul style="list-style-type: none"> <li>Never disassemble the machine. Disassembling it can result in electric shock hazards or damage to the machine.</li> <li>Before maintenance, be sure to turn off the power switch and unplug the power cable; otherwise, an unexpected accident may occur.</li> </ul>
	<ul style="list-style-type: none"> <li>Prevent moisture from entering the machine. Moisture inside the machine can cause electric shock hazards or damage to the machine.</li> </ul>
	<ul style="list-style-type: none"> <li>To ensure stable ink jetting, it is necessary for the machine to eject a small amount of ink (flushing) regularly when a printing (outputting) operation has not been performed for a long time.</li> <li>When the machine is not to be used for a long time, turn off only the power switch on the front side, leave the main power switch at the right side turned ON (in the position of   ), and leave the power cable connected.</li> </ul>
	<ul style="list-style-type: none"> <li>Do not wipe the nozzle face of the heads, wiper, caps, etc. with water or alcohol. Doing so can cause nozzle clogging or machine failure.</li> <li>Do not use benzene, thinner, or any chemical agent containing an abrasive. Such materials can deteriorate or deform the surface of the cover.</li> <li>Do not apply a lubricant, etc. to any parts inside the machine. Doing so can cause printing failure.</li> <li>Be careful that the cleaning solution, ink, etc. not to stick to the cover because this may cause the surface of the cover to deteriorate or deform.</li> </ul>


## About Cleaning Solution

Use the cleaning liquid dedicated for the ink being used.

Type of Ink	Applicable maintenance washings
Sublimation dye ink	Cleaning Liquid Bottle Kit A29 (SPC-0137) [Sold separately]

## Cleaning the Exterior Surfaces


When the exterior surfaces of the machine are stained, dampen a soft cloth with water or a neutral detergent diluted with water, squeeze it, and wipe the surfaces with the cloth.



## Cleaning the Platen

The platen easily gets dirty with lint, paper dust, etc. generated when a media is cut.

Wipe off conspicuous stains with a soft-hair brush, a dry cloth, a paper towel, etc.



- When the platen is stained with ink, wipe it off with a paper towel containing a small amount of cleaning solution for maintenance.



- Before cleaning the platen, make sure that the platen has cooled adequately.
- Because dust and dirt are easily accumulated in the slots for holding a media and cutting paper (cutter line), be sure to clean these parts carefully.


## Cleaning the Media Sensor

The media sensors are located on the platen in the backside and the bottom surface of the head. When the sensor is covered with dust, etc., it may cause false detection of media.

Using a cotton swab, remove the dust, etc. accumulated on the surface of the sensor.


When cleaning the sensor on the lower surface of the head is cleaned, move the carriage to the left end by the operations of step 1 of P.4-10 "Cleaning the Ink Head and the Area around It", and then clean it.

The backside of the machine



Media sensor

The lower surface of the head



Media sensor




- Don't touch the cutter around the media sensor. Sharp cutter tip may injure you.

## Cleaning the Media Press

When the media press is covered with lint, dust, etc., a media cannot be fed normally during printing or dust sticks to the nozzles, which may result in abnormal printing.


Clean the media press regularly.



Media press


# About MAINTENANCE MENU

This provides various settings for doing maintenance on the machine.  
The following items can be set in Maintenance settings.



- FUNC1** : Press this to select MAINTENANCE MENU, or to switch to the previous screen.
- FUNC2** : Press this to use the maintenance function.
- FUNC3** : Press this to switch to the next screen.
- ▲ ▼** : Use these to select a setting item.
- ENTER** : Press this to confirm a setting, etc..

## ◆ MAINTENANCE MENUs at-a-glance



## ◆ Screen transition when **FUNC2** key is pressed





## MAINTENANCE MENUs at-a-glance

Item	Set value	Meaning
STATION MAINTENANCE	For carrying out maintenance on the carriage and station periphery.	
	CARRIAGE OUT (☞ P.4-6)	_____ Moves the carriage out, for carrying out cleaning of the cap periphery, head, wipers, etc.
	NOZZLE WASH (☞ P.4-7)	1 to 99min Soaks the nozzle surfaces in maintenance cleaning fluid, for carrying out recovery from nozzle clogging or bent.
	DISWAY WASH (☞ P.4-8)	_____ Executes washing of the suction pump tubes.
	CUSTODY WASH (☞ P.4-8)	1 to 99min Carried out when the machine is going to be out of use for an extended period. Washes the nozzles and tubes beforehand, to keep the machine in fine condition.
	WIPER EXCHANGE (☞ P.4-13)	Used when replacing the wiper. If the wiper is replaced, the number of times the wiper was used that is managed in this device is reset.
AUTO MAINTENANCE (☞ P.4-11)	For having the various maintenance functions executed automatically. Set the execution interval for each maintenance function.	
	REFRESH	The set value will differ according to the ink type being used. For setting the activation interval for refresh.
	CLEANING	For setting the activation interval for head cleaning.
	CLEANING TYPE	NORMAL/ SOFT/ HARD For setting the type of head cleaning.
INK FILLING (☞ P.4-12)	Supplies ink to correct nozzle clogging.	
INK TANK EXCHANGE (☞ P.4-15)	Resets or corrects the used count for the waste ink tank.	

# Maintaining the Capping Station

Maintain the ink cap, wiper, etc. located in the capping station. (SATION MAINT.)

- Important!**
- To keep the nozzle status normal, perform wiper cleaning frequently.

The ink cap and wiper function as follows.

- Wiper** : It wipes off ink sticking to the head nozzles.
- Ink cap** : It prevents the head nozzles from clogging due to dryness.

As the machine is used repeatedly, the wiper and ink cap gradually become dirty with ink, dust, etc. If nozzle missing cannot be corrected even after head cleaning (☞ P.2-11) has been performed, use a maintenance liquid 01 kit and clean stick.

## Tools required for Maintenance

- Cleaning Liquid Bottle Kit A29 (SPC-0137)
- Clean stick (SPC-0527)
- Gloves
- Goggles



- Be sure to wear the supplied goggles and gloves when maintaining the capping station. Otherwise, you may get ink in your eyes.
- Do not move the carriage out of the capping station by hand. When it is desirable to move the carriage, press the [FUNC1] key to execute the carriage-out. (☞ P.4-6 Steps 1 to 2)

## Cleaning the Wiper and Cap

It is recommended that the wiper and cap be cleaned frequently in order to maintain the high image quality of the machine and keep the machine itself in good working order.

- Important!**
- Replace the wiper with a new one when it is extremely dirty or bent. (☞ P.4-13)
  - When cleaning the wiper, be careful that lint from the clean stick does not get left on the wiper. Remaining lint may cause image quality to deteriorate.


**1** Press the **FUNC1 (MENU)** key in **LOCAL**.

- MAINTENANCE MENU will be displayed.

**2** Press the **ENTER** key twice.


- The carriage moves onto the platen.

**3** Open the front cover.




**4** Remove the wiper.

- Pull out the wiper by holding the protrusions at its both ends.




**5** Clean the wiper and bracket.

- Wipe off the ink sticking to the wiper and bracket with a clean stick dipped in cleaning solution for maintenance. Wipe off so that cleaning solution for maintenance will not remain.




**6** Clean the wiper slider.

- Wipe off the ink sticking to the wiper slider with a clean stick dipped in cleaning solution for maintenance. Wipe off so that cleaning solution for maintenance will not remain.




**7 Set the wiper at the original position.**

- Insert the wiper by holding the protrusions at its both ends.

**8 Clean the cap rubber.**

- Wipe off the ink sticking to the cap rubber with a clean stick dipped in maintenance solution for maintenance.
- Wipe off so that maintenance solution for maintenance will not remain.

**9 Press the **ENTER** key after the cleaning.****10 Close the front cover then press the **ENTER** key.**

- After its initial operation, the machine returns to step1.

**Washing the Head Nozzle****1 Press the **FUNC1** (MENU) key and the **ENTER** key in LOCAL.**

- MAINTENANCE MENU will be displayed.

**2 Press the **ENTER** key.**

- "STATION" will be selected.



**3 Press the **DOWN** key, and press the **ENTER** key.**

- "NOZZLE WASH" will be selected and the carriage will move onto the platen.

**4 Open the front cover.****5 Clean the wiper and the bracket, and press the **ENTER** key.**

- (1) Open the right maintenance cover then pull out it by holding projections at both ends of the wiper.


- (2) Clean the wiper and bracket with a clean stick dipped in maintenance washing liquid for maintenance. (SPC-0137)
  - Wipe off so that maintenance washing liquid for maintenance will not remain.
- (3) Insert it in the original position by holding the projections at both ends of the wiper.

**6 Clean the cap rubber, and press the **ENTER** key.**

- Wipe off the ink sticking to the cap rubber with a clean stick dipped in maintenance washing liquid for maintenance.
- Wipe off so that maintenance washing liquid for maintenance will not remain.
- At this time, the discharge passage is cleaned automatically.

**7 Fill up the cap with cleaning solution for maintenance.**

- Suck maintenance solution into a dropper and fill up the cap with it. Fill up the cap with maintenance solution on the verge of overflow from the cap.

**8 Close the front cover, and press the **ENTER** key.**

**9** Press **▲ ▼** to set the time for the maintenance washing liquid to be left as it is, and press the **ENTER** key.

- **Set value** : 1 to 99 minutes (Unit: minute)
- The maintenance washing liquid filled in the cap is absorbed.
- "Please Wait" will be displayed in the display until the time you set has elapsed.

**Important!** • When nozzle missing is not cleared even after this washing is carried out several times, contact the distributor in your region or our service office.

### Washing the Ink Discharge Passage

Wash the ink discharge passage regularly (about once a week) to prevent the head nozzles from clogging due to ink coagulation inside the passage.

**Important!** • Before washing the ink discharge passage, make sure that the maintenance washing liquid is set. If the maintenance washing liquid is not set, washing operation will not be conducted and the passage could be clogged.

**1** Press the **FUNC1 (MENU) ▲ ▼** **ENTER** key in LOCAL.

- MAINTENANCE MENU will be displayed.


**2** Press the **ENTER** key.

- "STATION" will be selected.

**3** Press **▼** twice, and press the **ENTER** key.

- "DISWAY WASH" will be selected and the carriage will move onto the platen.
- Dry suction operation is performed repeatedly until the washing work is completed.

**4** Open the front cover.




**5** Press the **ENTER** key.

- Dry suction operation is performed repeatedly until the washing work is completed.

**6** Fill up the cap with cleaning solution for maintenance.

- Suck maintenance solution into a dropper and fill up the cap with it. Fill up the cap with maintenance solution on the verge of overflow from the cap.



**7** Close the front cover and press the **ENTER** key.

### When the Machine Is Not Used for a Long Time

When the machine is not going to be used for a week or more, use the cleaning function for custody to clean the head nozzles and ink discharge passage. After this, keep the machine in custody.

- Important!**
- Use the machine with always turning "ON" the main power. The function preventing nozzle clogging operates automatically to protect the head of the nozzle.
  - The head nozzle may result in nozzle clogging if the main power switch is left OFF for a long time.

#### Check the items on the right beforehand.

Is **[NEAR END]** or **[INK END]** displayed?

- The cleaning solution or ink is absorbed when the nozzles are washed. At this time, if the state of "no ink" or "almost no ink" is detected, the nozzle washing operation cannot start.
- Replace the cartridge with another from which the state of "almost no ink" or "no ink" is not detected.



- When the warning messages "Check waste ink" are indicated, check the waste ink tank, and then operate it, referring to P.4-13 "If a Waste Ink Tank Confirmation Message Appears" according to the situation.

**1** Press the **FUNC1 (MENU) ▲ ▼** **ENTER** key in LOCAL.

- MAINTENANCE MENU will be displayed.

**2** Press the **ENTER** key.

- "STATION" will be selected.

### 3 Press 3 times, and press the key.


- “CUSTODY WASH” will be selected and the carriage will move onto the platen.

**Important!**

- Until wiper/ bracket cleaning is completed, “COMPLETED” is displayed on the screen. After the work up to the step 3 is completed, press the [ENTER] key. If you press the [ENTER] key before cleaning is completed, the machine moves to the next washing procedure.

### 4 Clean the wiper and the bracket.

- (1) Open the front cover then pull out it by holding projections at both ends of the wiper.
- (2) Clean the wiper and bracket with a clean stick dipped in cleaning solution for maintenance. (SPC-0137) Wipe off so that cleaning solution for maintenance will not remain.
- (3) Insert it in the original position by holding the projections at both ends of the wiper.




### 5 Press the key.

**Important!**

- Until wiper cleaning is completed, [COMPLETED (NEXT): ENT] is displayed on the screen. After the work up to the step 5 is completed, press the [ENTER] key. If you press the [ENTER] key before cleaning is completed, the machine moves to the next washing procedure.

### 6 Clean the cap rubber.

- Wipe off the ink sticking to the cap rubber with a clean stick dipped in maintenance solution for maintenance.
- Wipe off so that maintenance solution for maintenance will not remain.
- At this time, the discharge passage is cleaned automatically.




### 7 Press the key.

**Important!**

- Until washing liquid is filled, [COMPLETED (NEXT): ENT] is displayed on the screen. After the work up to the Step 8 is completed and you close the front cover, press the [ENTER] key. If you press the [ENTER] key before washing liquid is filled, the carriage returns to the original position.

### 8 Fill up the cap with cleaning solution for maintenance.

- Suck maintenance solution into a dropper and fill up the cap with it. Fill up the cap with maintenance solution on the verge of overflow from the cap.



### 9 Close the front cover and press the key.

### 10 Press to set the time for the cleaning solution to be left as it is.

- Set Value: 1 to 99 min (by the unit of 1 min)


### 11 Press the key.

- The nozzles are washed.
- When the nozzles have been completely washed, the head moves to the maintenance position.

### 12 Open the front cover.

### 13 Fill up the cap with cleaning solution for maintenance.

- Suck maintenance solution into a dropper and fill up the cap with it. Fill up the cap with maintenance solution on the verge of overflow from the cap.



### 14 Close the front cover and press the **ENTER** key.

- After its initial operation, the machine returns to step2.

## Cleaning the Ink Head and the Area around It

Because the ink head employs a very precise mechanism, due care needs to be taken when it is cleaned.

Using a clean stick, etc., rub off gelatinous ink or dust that may stick to the lower part of the slider and the area around the ink head. In doing so, never rub the nozzles of the head.

#### Tools required for cleaning

• Clean stick (SPC-0527)	• Gloves
• Goggles	



- Be sure to wear the attached goggles and gloves when cleaning the area around the ink head. Otherwise, you may get ink in your eyes.
- The ink contains organic solvent. If you get the ink on your skin or in your eyes, wash it away with plenty of water immediately.

#### 1 Press the **FUNC1 (MENU)** and **ENTER** key in LOCAL.

- MAINTENANCE MENU will be displayed.


#### 2 Press the **ENTER** key twice.

- "CARRIAGE OUT" will be selected.

#### 3 Press the **DOWN** arrow, and press the **ENTER** key.



- "HEAD MAINTENANCE" will be selected and the carriage will move to the left end of this machine.

#### 4 Open the maintenance cover.



## 5 Use a clean stick soaked in maintenance cleaning fluid to wipe ink off the head surface or other surfaces.

- Never rub the nozzles.



Clean with a clean stick or a waste cloth.

## 6 Press the **ENTER** key after the cleaning.

## 7 Close the maintenance cover, and press the **ENTER** key.

- After its initial operation, the machine returns to LOCAL.

## Automatic Maintenance Function

To use this machine comfortably, you can set various maintenances to be performed automatically. Here, set performing intervals of various automatic maintenances.

You can prevent troubles such as ink clogging by performing automatic maintenance periodically (automatic maintenance function).

For the auto maintenance functions, the following items can be set:

- Important!** • When you perform maintenance manually, after manual maintenance is completed and when time set with the automatic maintenance function has passed, maintenance starts automatically.

Function name	Descriptions
REFRESH	The interval between each refreshing operation is set.
CLEANING (Interval)	The interval between each cleaning operation is set.
CLEANING (Type)	The cleaning type is set.

### Important!

- If the "Check waste ink" warning message is displayed, the operation set in the auto maintenance function is not carried out. Perform the operations of P.4-14 "Replace the waste ink tank with another" if required.
- When the power switch on the front of the machine is turned off, check the waste ink tank.

## Setting the Refreshing Intervals

The interval between each operation of ejecting a small amount of ink from the nozzles to prevent nozzle clogging is set.

### 1 Press the **FUNC1 (MENU)** **ENTER** key in LOCAL.

- MAINTENANCE MENU will be displayed.

### 2 Press **DOWN**, and press the **ENTER** key.

- "AUTO MAINTENANCE" will be selected.

### 3 Press the **ENTER** key.

- "REFRESH" will be selected.






### 4 Press **UP** **DOWN** to set the refreshing interval, and press the **ENTER** key.

- **Set value** : The set value will differ according to the ink type being used.

### 5 Press the **END/POWER** key several times to end the setting.








## Setting the Cleaning Intervals and Type

The cleaning type and the interval between each cleaning operation are set.

- 1 Press the **FUNC1 (MENU)**  **ENTER** key in LOCAL.
  - MAINTENANCE MENU will be displayed.
- 2 Press , and press the **ENTER** key.
  - "AUTO MAINTENANCE" will be selected.
- 3 Press the  several times to select "Interval" or "Type", and press the **ENTER** key.
- 4 Press   to select a set value, and press the **ENTER** key.
  - **Set value** : The set value will differ according to the ink type being used.
  - **Set value of type** : SOFT/ NORMAL/ HARD
- 5 Press the **END/POWER** key several times to end the setting.

## Fill up Ink

Supplies ink to correct nozzle clogging.

- 1 Press the **FUNC1 (MENU)**   **ENTER** key in LOCAL.
  - MAINTENANCE MENU will be displayed.
- 2 Press  timestwice, and press the **ENTER** key.
  - "FILL UP INK" will be selected.
- 3 Press   to select the filling type.
  - **Soft** : Use this in cases where head cleaning will not achieve recovery, such as when multiple clogged nozzles occur or nozzle cluster dropout occurs.
  - **Normal** : Use this if nozzle cluster dropout occurs in initial ink filling.
  - **Hard** : Use this in cases where the dumper has become empty, such as in dumper replacement.
- 4 Press the **ENTER** key.
  - If you selected "Soft" in step 4, a Select Fill Up Color screen will be displayed. If you selected "Normal" or "Hard", go to step 6.
- 5 Press   to select the filling color, and press the **ENTER** key.
- 6 Press the **ENTER** key.
  - Ink is supplied automatically.
- 7 Press the **END/POWER** key several times to end the setting.



# Replacing consumables

## Replacing the wiper

The wiper is consumable. When the display indicates the warning message “Replace a WIPER” it is necessary to check and replace the wiper, immediately replace the wiper with a new one.

Also, wipe ink sticking to the lower surface of the slider off.

**Important!**


- When the warning message for replacing wiper is shown, confirm whether there is no damage and fuzz at the top edge of the wiper film. If there is no damage on the top edge of the wiper film, it is possible to use the wiper continuously without replacing it.
- A cleaning wiper is an option. Buy one through the dealer in your region or at our service office.

**1** Press the **FUNC1 (MENU)**  **ENTER** key in LOCAL.

- MAINTENANCE MENU will be displayed.

**2** Press the **ENTER** key.


- “STATION” will be selected.

**3** Press  3 times, and press the **ENTER** key.

- “WIPER EXCHANGE” will be selected and the number of times the wiper was used will be reset.


**4** Press the **ENTER** key.

- The carriage will move onto the platen.




**5** Remove the wiper.

- Pull out the wiper by holding the protrusions at its both ends.



**6** Insert a new wiper.

- Insert the wiper by holding the protrusions at its both ends.



**7** Close the front cover, and press the **ENTER** key.

- After its initial operation, the machine returns to LOCAL.

## If a Waste Ink Tank Confirmation Message Appears

Ink used in head cleaning, etc. is stored in the waste ink tank on the lower right side of the machine. This machine counts the accumulated amount of discharged ink. When that reaches a specified amount, the machine displays a confirmation message. (When this message is displayed, consider the replacement of the waste ink tank.)



- The message is displayed when it reaches 80% (1.6L) of the 2L tank.

## Confirmation Message in LOCAL

**1** The warning message “Check waste ink” is displayed.

**2** Check the state of the waste ink tank

- When it is different from the actual amount, press **[▲][▼]** and correct.
- When you correct (80%), press the **[ENTER]** key to return to LOCAL.
- When you replace (disposal) and clear the count, perform the procedures in “Replace the waste ink tank with another”. (P.4-14)

## Replace the waste ink tank with another

**1** The warning message “Check waste ink” is displayed.

**2** Press the **FUNC2** (MAINT.) key.


**3** Check the state of the waste ink tank.

**4** If the amount of waste ink needs to be adjusted, press the **ENTER** key.


- Compare the amount of waste ink shown on the display and the amount you visually confirmed. If there is no major problem with the value shown on the display, instead of the [ENTER] key, press the [END] key and proceed to Step 6.

**5** Press **▲** **▼** to adjust the level, and press the **ENTER** key.


**6** Pull the waste ink tank stopper to open to the front.



**7** Pull it forward to remove by holding the waste ink tank handle.




- Put a cap on the waste ink tank removed.



**8**

**Replace the waste ink tank.**


- (1) Prepare a new waste ink tank (SPC-0117).
- (2) Insert the waste ink tank by holding a handle of the tank.



- Waste ink is equivalent to waste oil of industrial waste. Request an industrial waste disposal company for disposal of waste ink.

**9**

**Close the waste ink tank stopper.**



**10**

**Press the **ENTER** key.**

- The ink discharging amount that is controlled by the machine is reset and the message is cancelled.

### Replacing the waste ink tank before the waste ink tank confirmation message is displayed

if you replace the waste ink tank before the waste ink tank confirmation message is displayed (before the 2L tank is 80% (1.6L) full), set the waste ink information to 0% in the Information menu.

**1** Perform steps 6 through 9 in "Replace the waste ink tank with another" (P.4-14) to empty the waste ink tank.

**2** Press the **FUNC1 (MENU)** → **ENTER** key in LOCAL.

- MAINTENANCE MENU will be displayed.

**3** Press **ENTER** 4 times, and press the **ENTER** key.

- "INK TANK EXCHANGE" will be selected.

**4** Waste ink tank information is displayed.

**5** Press the **FUNC2 (v)**.

- The reset screen for the waste ink tank amount will be displayed.

**6** Press the **ENTER** key.

- The waste ink tank amount that is managed in this machine will be reset.

### Replacing the Cutter Blade

The cutter blade is consumable. When the cutter blade gets dull, replace it with a new one (SPA-0107).



- The blade is sharp. Be careful not to hurt yourself or anyone else.
- Store the cutter blade in a place that is out of the reach of children. In addition, dispose of used cutter blades according to regional laws and regulations.




- When replacing the cutter blade, it is recommended to place a sheet of paper under the cutter blade. This will help pick up the cutter blade if it drops.

**1** Press the **FUNC1 (MENU)** → **ENTER** key in LOCAL.

- MAINTENANCE MENU will be displayed.



**2** Press the **ENTER** key twice, and open the front cover.

- The carriage moves onto the platen.



**3** Replace the cutter unit by the carriage.

- (1) Loosen the screw of the cutter unit.
- (2) Remove the cutter unit.
- (3) Mount a new cutter unit.
- (4) Fasten the screw of the cutter unit to secure the cutter unit.



Cutter unit

**4** Close the FRONT cover.

**5** Press the **ENTER** key.



# Chapter 5

## Troubleshooting



### This chapter

describes the corrective measures to be taken for a phenomenon suspected to be trouble and the procedures to clear the error number displayed on the LCD.


Troubleshooting .....	5-2
Power does not turn on .....	5-2
The machine does not start printing .....	5-2
Media get jammed / media is soiled .....	5-2
Image quality is poor .....	5-3
Nozzle is clogged .....	5-3
Ink cartridge warning appears .....	5-4
When the ink leakage occurs .....	5-4
Warning / Error Messages .....	5-5
Warning messages .....	5-5
Error messages .....	5-7

# Troubleshooting

Take appropriate actions as described below before taking the trouble as a failure.  
If still the problem is not solved after troubleshooting, contact your dealer or an office of MIMAKI.


## Power does not turn on

In most cases, this is due to improper connection of the power cable for the machine or computer. Check that the power cable is connected properly.




## The machine does not start printing

This occurs when the data is not being transmitted to the machine properly.  
It can also occur when the printing function does not work properly or the media is not set correctly.



## Media get jammed / media is soiled

Media jamming or stained media is considered to be due to the use of an unsuitable media or improper setting of media.



## Image quality is poor

This section describes the corrective actions to be taken in case the image quality is not satisfactory.

Take remedy for particular problems with image quality. If the remedy does not work, contact your dealer or an office of MIMAKI.

Phenomenon	Measures
<b>White lines / blur / dark stripes (in the direction of travel of the heads)</b>	<ol style="list-style-type: none"> <li>(1) Execute the head cleaning. (☞ P.2-11)</li> <li>(2) Perform maintenance of the inside of the station. (☞ P.4-6)</li> <li>(3) Execute the [FEED COMP.] function. (☞ P.3-5)</li> <li>(4) If any pieces of paper or dust is attached on the path of the heads such as media press, remove it.</li> </ol>
<b>Characters are double- or triple-printed in the media feed direction</b>	<ol style="list-style-type: none"> <li>(1) Execute the [FEED COMP.] function. (☞ P.3-5)</li> </ol>
<b>Disagreement in print positions between outward trip and homeward trip</b>	<ol style="list-style-type: none"> <li>(1) Execute the [DROP POSITION] function. (☞ P.3-6)</li> </ol>
<b>Ink drops falling on media during printing</b>	<ol style="list-style-type: none"> <li>(1) Execute the wiper cleaning. (☞ P.4-6)</li> <li>(2) Execute the ink cap cleaning. (☞ P.4-6)</li> <li>(3) Clean around the head. (☞ P.4-10)</li> <li>(4) Execute the head cleaning [NORMAL]. (☞ P.2-11)</li> <li>(5) Set the INTERVAL WIPING operation. (☞ P.3-9)</li> </ol>

## Nozzle is clogged

When nozzle clogging is not dissolved even after the head cleaning referring to P.2-11, make sure the following operations.

- Wash the head nozzle by the operations of P.4-7.
- Wash the head nozzle surface by the operations of P.4-10.

### Ink cartridge warning appears

If an ink cartridge trouble is detected, the cartridge LED "red" is lit, and a warning message appears. None of printing, cleaning and all the other operations that use ink is available. In this case, replace the ink cartridge in question immediately.




- Once cartridge trouble is displayed, do not leave the ink cartridge without replacing it for a long time; otherwise, the machine will lose the nozzle clogging prevention function. If nozzles are clogged, the machine must be repaired by MIMAKI's service engineer.

### Displaying the description of ink cartridge trouble

The contents of cartridge error are confirmable by the following operations.

1

Press the  key in LOCAL.

2

Press the  key.

### When the ink leakage occurs

If the ink leakage occurs, unplug the power plug to turn off the main power switch, and contact our service office or distributor.



## Warning / Error Messages

If some trouble occurs, the buzzer sounds and the display shows a corresponding error message.  
Take an appropriate remedy for the displayed error.

### Warning messages

#### Errors when performing operations

Message	Cause	Solution
INVALID OPERATION :MEDIA UNDETECT	Operation cannot be performed because no media is detected.	<ul style="list-style-type: none"> <li>Execute after media is detected.</li> </ul>
INVALID OPERATION :MOTOR POWER OFF	The motor is OFF after the cover was opened etc.	<ul style="list-style-type: none"> <li>Return to LOCAL and execute the operation after completion of initialization.</li> </ul>
INVALID OPERATION INK ERROR	An ink error occurred.	<ul style="list-style-type: none"> <li>Execute the operation after replacing with a new ink cartridge.</li> </ul>
INVALID OPERATION COVER OPEN	The front cover or the maintenance cover is opened.	<ul style="list-style-type: none"> <li>Execute the operation after closing the cover.</li> </ul>
INVALID OPERATION DATA REMAIN	Data was received.	<ul style="list-style-type: none"> <li>Execute the operation after executing data clear. (☞ P.2-13)</li> </ul>

#### Message displayed in LOCAL

Message	Cause	Solution
Can't print/cartridge	Multiple ink errors (unusable ink) have occurred, making it impossible to feed ink (printing and cleaning, etc.).	Replace with a new ink cartridge.
Check waste ink	The waste ink tank count has exceeded the prescribed amount.	Check the amount of waste ink in the waste ink tank. Conduct maintenance and waste ink tank replacement, and reset the amount of waste ink.
Replace WIPER	The used count of wiper has exceeded the prescribed number.	Execute maintenance, station maintenance and wiper exchange and replace the wiper.
NO MEDIA	No media is set. Or, the sensor is faulty.	Set the media. If the same error message still appears after setting the media, contact our service desk or your local distributor to call for service.
DATA REMAIN	Print data is received in LOCAL.	Shift to REMOTE and execute printing. Or, execute data clear and cancel printing.

## Ink Error

Ink error is displayed also in the local guidance. (P.3-21)

Message	Cause	Solution
WRONG INK IC	The IC chip of the ink cartridge cannot be read normally.	<ul style="list-style-type: none"> <li>Remove the cartridge generating the warning once and install it again.</li> <li>If the same warning message still appears, contact your local distributor to call for service.</li> </ul>
INK TYPE	The ink of the ink cartridge is different in type from the ink currently supplied.	<ul style="list-style-type: none"> <li>Check the ink type of the cartridge generating the warning.</li> </ul>
INK COLOR	The ink of the ink cartridge is different in color from the ink currently supplied.	<ul style="list-style-type: none"> <li>Check the ink color of the cartridge generating the warning.</li> </ul>
WRONG CARTRIDGE	An error occurred in the IC chip information of the ink cartridge.	<ul style="list-style-type: none"> <li>Check the cartridge generating the warning. Make sure there is no nozzle clogging</li> </ul>
NO CARTRIDGE	An ink cartridge has not been installed in the slot.	<ul style="list-style-type: none"> <li>Install an appropriate cartridge in the slot generating the warning.</li> </ul>
INK END	The ink of the ink cartridge has been completely used up.	<ul style="list-style-type: none"> <li>Replace the cartridge generating the warning with a new one.</li> </ul>
INK NEAR END	There is only a little bit of ink left in the ink cartridge.	<ul style="list-style-type: none"> <li>The ink will soon be used up. Be careful.</li> </ul>
Expiration	The ink of the ink cartridge has been nearly used up.	<ul style="list-style-type: none"> <li>Replace the cartridge generating the warning with a new one. However, it can be used until the month after next.</li> </ul>
Expiration:1MONTH	The specified expiration date of an ink cartridge has passed.(one month has passed after the specified expiration date).	<ul style="list-style-type: none"> <li>The expiration date has passed. However, you can use it until the end of the following month.</li> </ul>
Expiration:2MONTH	The expiration date of an ink cartridge has passed (two months have passed after the specified expiration date).	<ul style="list-style-type: none"> <li>More than two months have passed after the expiration date. Replace the cartridge generating the warning with a new one.</li> </ul>
ERROR 63c INK REMAIN ZERO	The ink remaining has become 0. (Only when ink end / 4 color ink set)	<ul style="list-style-type: none"> <li>Replace the cartridge with a new one.</li> </ul>

## Error messages

When an error message is displayed, eliminate the error according to the chart below.

If the same error message appears again, contact your dealer or an office of MIMAKI to call for service.

Message	Cause	Solution
ERROR 122 CHECK:SDRAM	SDRAM is defective.	<ul style="list-style-type: none"> <li>• Turn off the power to the machine and turn it on after a while.</li> <li>• If the same error message appears again, contact your local distributor to call for service.</li> </ul>
ERROR 128 HDC FIFO OVER	Head control circuit board is defective.	
ERROR 128 HDC FIFO UNDER		
ERROR 129 BATTERY EXCHANGE	The battery life end of the internal clock is detected.	<ul style="list-style-type: none"> <li>• Contact your local distributor to call for service.</li> </ul>
ERROR 130 HD DATA SEQ	Head data transferring sequence error occurred.	<ul style="list-style-type: none"> <li>• Turn off the power to the machine and turn it on after a while.</li> <li>• If the same error message appears again, contact your local distributor to call for service.</li> </ul>
ERROR 146 E-LOG SEQ	Sequential number abnormality of the event log occurred.	
ERROR 151 Main PCB V1R2	Error occurs in the power supply system of the main board.	
ERROR 152 Main PCB V2R5		
ERROR 153 Main PCB V3R3		
ERROR 154 Main PCB V05		
ERROR 157 Main PCB VTT		
ERROR 16e Main PCB V3R3B		
ERROR 15f HEAD DRIVE HOT		
ERROR 171 NEW HEAD CONNECT		
ERROR 186 HDC OVERFLOW	An error is detected on the waveform printed on.	
ERROR 186 HDC UNDERFLOW		
ERROR 187 HDC SLEW RATE		
ERROR 188 HDC MEMORY		
ERROR 18a Main PCB V_CORE	An error occurred in the main PCB .	

Message	Cause	Solution
ERROR 18c Main PCB V12	An error occurred in the main PCB .	<ul style="list-style-type: none"> <li>• Turn off the power to the machine and turn it on after a while.</li> <li>• If the same error message appears again, contact your local distributor to call for service.</li> </ul>
ERROR 190 Main PCB V42-1		
ERROR 192 COMIO PCB V1R2	An error occurred in the COM16/32IO PCB .	
ERROR 193 COMIO PCB V2R5		
ERROR 194 COMIO PCB V3R3		
ERROR 195 COMIO PCB V24		
ERROR 1a0 SLDR2H PCB V1R2	An error occurred in the SLIDER2H PCB .	
ERROR 1a6 SLDR2H PCB V2R5		
ERROR 1a7 SLDR2H PCB V3R3		
ERROR 1a8 SLDR2H PCB V5		
ERROR 1a9 SLDR2H PCB V42		
ERROR 201 COMMAND ERROR	The machine received some data other than print data. Or, an error occurred in the transmitted print data.	<ul style="list-style-type: none"> <li>• Securely connect the interface cable in position.</li> <li>• Use an interface cable conforming to the specifications.</li> </ul>
ERROR 202 PARAMETER ERROR	An error occurred in the transmitted print data.	
ERROR 304 USB INIT ERR	An error occurred in the communication of USB.	<ul style="list-style-type: none"> <li>• Turn off the main power to the machine and turn it on after a while.</li> <li>• If the same error message appears again, contact your local distributor to call for service.</li> </ul>
ERROR 305 USB TIME OUT		
ERROR 401 MOTOR X	An excessive load was applied to the X motor.	
ERROR 402 MOTOR Y	An excessive load was applied to the Y motor.	
ERROR 403 X CURRENT	An error due to an excessive current of the X motor was detected.	
ERROR 404 Y CURRENT	An error due to an excessive current of the Y motor was detected.	
ERROR 505 MEDIA JAM	The media jam occurs.	<ul style="list-style-type: none"> <li>• Remove the media and reset it.</li> </ul>

Message	Cause	Solution
ERROR 509 HDC POSCNT	An error occurred in the control position.	
ERROR 50a Y ORIGIN	Y-origin could not be detected.	<ul style="list-style-type: none"> <li>• Turn off the main power to the machine and turn it on after a while.</li> <li>• If the same error message appears again, contact your local distributor to call for service.</li> </ul>
ERROR 50f L-SCALE BLACK	Abnormal linear scale.	
ERROR 529 LEnc.Count HPC[____]		
ERROR 52a LEnc.Count HDC[____]		
ERROR 52c MEDIA WIDTH SENSOR	The media width could not be correctly read.	<ul style="list-style-type: none"> <li>• Check the media set position. (☞ P.2-4)</li> <li>• Clean the media sensor. (☞ P.4-3)</li> <li>• Turn the main power OFF, wait a while, and then turn it ON again.</li> </ul>
ERROR 516 MEDIA SET POSITION R	The media is set outside the proper area.	<ul style="list-style-type: none"> <li>• Check the media set position. (☞ P.2-5)</li> </ul>
ERROR 528 PUMP MOTOR SENSOR	Pump sensor detection error	<ul style="list-style-type: none"> <li>• Turn the main power OFF, wait a while, and then turn it ON again.If the same error message appears, contact our service desk or your local distributor to call for service.</li> </ul>
ERROR 602 CARTRIDGE END	Ink end (cannot be used, can only be used when cleaning with the 4-color ink set)	<ul style="list-style-type: none"> <li>• Replace with new ink.</li> </ul>
ERROR 608 WRONG INK IC	The ink cartridge IC chip cannot be correctly read.	<ul style="list-style-type: none"> <li>• Make sure that the cartridge is correctly inserted.</li> <li>• Reinsert the cartridge.</li> <li>• Turn the main power OFF, wait a while, and then turn it ON again.If the same error message appears, contact our service desk or your local distributor to call for service.</li> </ul>
ERROR 627 RE-INSERT CARTRIDGE	There is a slot in which the cartridge has not been inserted more than a certain time.	<ul style="list-style-type: none"> <li>• Set a cartridge.</li> </ul>
ERROR 628 WRONG INK CARTRIDGE	A problem has occurred in the ink cartridge IC chip information. The used count has exceeded the prescribed value.	<ul style="list-style-type: none"> <li>• Make sure there is no nozzle clogging (especially for the white ink).</li> </ul>
ERROR 63c INK REMAIN ZERO	Remaining ink is 0 in the cartridge (ink end/ only when the 4-color ink set is used)?	<ul style="list-style-type: none"> <li>• Replace with new ink.</li> </ul>
ERROR 901 INVALID OPERATION	Due to a certain error, the function cannot be performed.	<ul style="list-style-type: none"> <li>• Return to the local screen, check the error status and take a countermeasure.</li> </ul>
ERROR 902 DATA REMAIN	There remains received data that has not yet been printed.	<ul style="list-style-type: none"> <li>• Execute the data clear function. (☞ P.2-13)</li> </ul>
ERROR 90d NO HEAD SELECT	An error occurred in the mounted heads.	<ul style="list-style-type: none"> <li>• Turn off the main power to the machine and turn it on after a while.</li> <li>• If the same error message appears again, contact your local distributor to call for service.</li> </ul>

Message	Cause	Solution
ERROR 90f PRINT AREA SHORT	The media width or the media length required for printing is not enough.	<ul style="list-style-type: none"> <li>• Change the media to the one with enough width or length.</li> <li>• When the media width narrows because the origin moved, slide the origin to the right to widen the effective media width.</li> </ul>
ERROR 04 PARAM ROM	An error occurred in the main PCB FROM.	<ul style="list-style-type: none"> <li>• Turn off the main power to the machine and turn it on after a while.</li> <li>• If the same error message appears again, contact your local distributor to call for service.</li> </ul>

## SYSTEM HALT

Message	Solution
SYSTEM HALT (*) 000 : MESSAGE	<ul style="list-style-type: none"> <li>• Turn off the main power to the machine and turn it on after a while.</li> </ul> <p>If the same error message appears again, check the number and contact your local distributor to call for service. ("000" is the error No.)</p>
SYSTEM HALT (*) 406 : WIPER ORG	<ul style="list-style-type: none"> <li>• Perform cleaning around the wiper.</li> <li>• Turn off the main power to the machine and turn it on after a while.</li> </ul> <p>If the same error message appears again, check the number and contact your local distributor to call for service.</p>

# Chapter 6

## Appendix



### This chapter

contains the lists of the specifications and functions of this machine.

Specifications .....	6-2
Machine specifications .....	6-2
Ink specifications .....	6-3
Setting orders depending on ink type .....	6-4
Setting orders of ink cartridges .....	6-4
Sheet for inquiry .....	6-5

# Specifications

## Machine specifications

Item		JV300-130A	JV300-160A
Print head	Method	Drop-on-demand piezoelectric print heads	
	Specification	2 head staggered	
Printing mode (scan x feed)		360x360dpi/ 540x360dpi/ 540x720dpi/ 720x1080dpi/ 720x1440dpi/ 1440x1440dpi	
Usable inks		Sublimation dye ink (Sb) : 6-colors (Y,M,BI,K or Dk,LBI,Lm)	
Ink supply		Supplying from ink cartridges through tubes.Ink cartridge replacement type : Supplying by Toggle switch over with 2 cartridges/color (4-colors ink set)	
Capacity of ink cartridge		Y,M,BI,K, Dk,LBI,Lm : 440cc cartridge	
Usable media		Photo-paper , Synthetic paper , Duplex paper	
Max. printing width		1361mm (53.6in)	1610mm (63.4in)
Roll Media size	Maximum	1371mm (54.0in)	1620mm (63.8in)
	Minimum	210mm (8.3in)	
	Thickness	1.0mm or less (0.04in or less)	1.0mm or less (0.04in or less)
	Roll outside diameter <sup>*1</sup>	Paper media : $\Phi$ 250mm or less ( $\Phi$ 9.8in or less) Other media : $\Phi$ 210mm or less ( $\Phi$ 8.3in or less)	
	Roll weight <sup>*1, *2</sup>	40kg or less (88.2lb or less)	
	Roll inside diameter	2 or 3 inches	
	Printing surface	Side facing outward	
Roll end treatment	The roll end is gently fixed to the core with weak-adhesive tape or weak glue for easy removal.		
Leaf media size	Maximum	1371mm (54.0in)	1620mm (63.8in)
	Minimum	210mm (8.3in)	
Margin	Leaf media	Left end and right end : 15 mm (Default) Front :120 mm Rear : 150 mm (Left end and right end : 0.6in (Default) Front :4.7in Rear : 5.9in)	
	Roll media	Left end and right end : 15 mm (Default) Front :120 mm Rear : 150 mm (Left end and right end : 0.6in (Default) Front :4.7in Rear : 5.9in)	
Distance accuracy	Absolute accuracy	Whichever the larger one of $\pm 0.3$ mm or $\pm 0.3$ % of the designated (Whichever the larger one of $\pm 0.01$ in or $\pm 0.3$ % of the designated)	
	Reproducibility	Whichever the larger one of $\pm 0.2$ mm or $\pm 0.1$ % of the designated (Whichever the larger one of $\pm 0.008$ in or $\pm 0.1$ % of the designated)	
Perpendicularity		$\pm 0.5$ mm / 1000 mm ( $\pm 0.02$ in / 39.4 in)	
Media skew		5 mm or less / 10 m (0.2 in or less / 32.8 ft)	
Head height adjustment		Select for manual 3-stage (2.0/2.5/3.0) + 1 mm or + 2 mm at installation. Base height can be raised. (Select for manual 3-stage (2.0/2.5/3.0) + 0.04 in or +0.08 in at installation. Base height can be raised.)	
Cutting of media		Cutting of Y direction by the head cutter. Cutting accuracy (steps) : 0.5 mm or less. (0.02 in or less.)	
Waste ink tank		Bottle type ( 2,000 cc)	
Interface		USB 2.0 (Ethernet 10 BASE/ 100 BASE E-mail function)	
Command		MRL- IV	
Noise	during standby	Less than 58 dB (A) (FAST-A, Front & Rear & Left & Right 1 m) (Less than 58 dB (A) (FAST-A, Front & Rear & Left & Right 3.3ft))	
	during continuous printing <sup>*3</sup>	Less than 65 dB (A)	
	during discontinuous printing	Less than 70 dB (A)	
Safety Standard		VCCI-Class A, FCC-Class A, UL 60950, CE Marking (EMC,Low Voltage Directive,Machinery Directive, RoHS Directive), CB Report, RoHS	
Power		AC100 - 120V/ 220 - 240V $\pm 10\%$ 50/60Hz $\pm 1$ Hz	
Power consumption		1440W or less (AC 100 - 120V) / 1920W or less (AC 220 - 240V)	



Item		JV300-130A	JV300-160A
Recommended Environment	Available temp.	20 °C to 30 °C (68 °F to 86 °F)	
	Humidity	35 to 65% Rh (No condensation)	
	Guaranteed temp.	20 °C to 25 °C (68 °F to 77 °F)	
	Temperature change	± 10 °C / h or less (± 50 °F / h or less)	
	Dust	Equivalent to normal office level	
	Highest operation height	2000 m (6561.7 ft)	
Weight		170 kg (374.8lb)	200 kg (440.9lb)
Outside dimensions	Width	2525mm (99.4in)	2775mm (109.2in)
	Depth	700mm (27.6in)	
	Height	1392 mm (54.8in)	

\*1. It is outside diameter and weight after take-up media.

\*2. Without deflection of the roll when it is retained at both ends.

\*3. Operating Condition: Full load Measuring Method: According to clause 1.7.4.2 of Machinery Directive 2006/42/EC

## Ink specifications

Item		Sublimation dye ink
Supply		Dedicated sublimation dye ink cartridge
Color		Black ink cartridge Blue ink cartridge Magenta ink cartridge Yellow ink cartridge Light blue ink cartridge Light magenta ink cartridge Deep black ink cartridge
Ink capacity		440cc per cartridge
Shelf life		The period is printed on the ink cartridge. Within three months after opening the package even in the available period.
Storage temperature	Storage	10 to 35°C (Average daily temperature) (50 to 95°F (Average daily temperature)) Be sure to keep a vessel in the airtight condition. Be sure to keep a vessel in a dry, well-ventilated, cool and dark location.
	Transportation	0 to 40°C (32 to 104°F) Avoid the condition lower than 0 °C and higher than 40 °C. (Avoid the condition lower than 32 °F and higher than 104 °F.)



- Do not disassemble ink cartridges and do not refill them with ink.
- Ink could freeze if kept in a cold place for an extended period.
- When aqueous ink is used, if the ink freezes, the quality is changed and the ink becomes unusable.  
Store the ink in an environment that will not freeze the ink.

# Setting orders depending on ink type


The setting value and the setting orders of the ink cartridges differ depending on the ink type you use.

## Setting orders of ink cartridges

The orders of ink cartridges set in the ink station differ depending on the ink set you use.



- Set the ink cartridge according to the cartridge label under the ink station.



<b>4-colors model</b>	M	M	Bl	Bl	Y	Y	K	K
<b>8-colors model</b>	M	Or	Bl	Lk	Y	Lm	K	LBl

# Sheet for inquiry

Use this sheet for troubles and abnormal functions of the machine.  
Fill in the following necessary items, and then fax the sheet to our sales office.

<b>Company name</b>	
<b>Person in charge</b>	
<b>Telephone number</b>	
<b>machine model</b>	
<b>Operating OS</b>	
<b>Machine information *1</b>	
<b>Error message</b>	
<b>Contents of inquiry</b>	

\*1. Refer to "Confirming Machine information" of "Convenient using" then fill in necessary information. (☞ P.3-20)



## **JV300-130/160A Operation Manual**

---

---

April 2017

**MIMAKI ENGINEERING CO.,LTD.**

2182-3 Shigeno-otsu, Tomi-shi, Nagano 389-0512 JAPAN

---

---

D202740-13-14042017

