

## DS-1600/1800 シリーズ

# インクの追加に伴う操作方法の変更について

この度は、DS-1600/1800 シリーズをお買い上げいただき誠にありがとうございます。

DS-1600/1800 シリーズのファームウェアバージョン 4.10 から、昇華転写インク [Sb51] をお使いになれます。それに伴い、下記の各設定で昇華転写インク [Sb51] を選択できるようになります。

| タイトル                               | 昇華転写インク [Sb51] 選択箇所 |      |   |
|------------------------------------|---------------------|------|---|
| 使用するインクの種類を設定する<br>[インクタイプ]        | 取扱説明書<br>P.3-19     | 手順 5 | ジョグキー【▲】【▼】で次の3つの中からインクタイプを選びます。  |
| 使用中のインクの種類と異なるインクを装填する場合 [インクコウカン] | 取扱説明書<br>P.4-26     | 手順 3 | <ul style="list-style-type: none"> <li>• [Sub] : 昇華転写インク</li> <li>• [TPig] : 捺染顔料インク</li> </ul> |
|                                    |                     | 手順 8 | <ul style="list-style-type: none"> <li>• [Sb51] : 昇華転写インク Sb51</li> </ul>                       |

## DS-1600/1800 Series

# Change of Operation by the Addition of Ink

Thank you for purchasing DS-1600/1800 series.

Sublimation transfer ink [Sb51] is available on DS-1600/1800 series with firmware version 4.10 or later.

Sublimation transfer ink [Sb51] can be selected by the following settings.

| Title  | The step to select sublimation transfer ink [Sb51] |        |   |
|--|--|--------|---|
| Setting the type of ink to be used [INK TYPE]                | Operation Manual P.3-19                            | Step 5 | Select the type of ink from the following three types with the jog key [▲][▼].  |
| When charging ink different from the one in use [INK CHANGE] | Operation Manual P.4-26                            | Step 3 | <ul style="list-style-type: none"> <li>• [Sub] : Sublimation dye ink</li> <li>• [TPig] : Textile pigment ink</li> <li>• [Sb51] : Sublimation transfer ink Sb51</li> </ul> |
|  |  | Step 8 |   |